
**OPERATIONS
AND
PROGRAMMING
MANUAL**

MODEL 5085

***MERIDIAN*
NEUTRON SURVEY METER**

November 2000

Health Physics Instruments

330 D South Kellogg Ave.

Goleta, CA 93117

Table of Contents

<u>SPECIFICATIONS</u>	<u>1</u>
A. MECHANICAL	1
B. ELECTRICAL	1
C. OPERATIONAL	1
D. RESPONSE	1
E. ENVIRONMENTAL	1
<u>II. INTRODUCTION</u>	<u>2</u>
<u>III. QUICK START</u>	<u>2</u>
<u>IV. OPERATION</u>	<u>3</u>
A. TURN ON AND OFF	3
B. EMERGENCY RESET AND CONTRAST	3
<u>V. MODES</u>	<u>4</u>
A. RATE	4
B. INTEGRATE	4
C. SETTING THE TIME	4
<u>VI. OPERATIONAL</u>	<u>5</u>
A. DETECTOR CONNECTION	5
B. LOW BATTERY	5
C. BATTERY CHANGE	5
D. DEADTIME CORRECTION	5
<u>VII. OPERATION OF THE RS232 OPTION</u>	<u>6</u>
A. OPERATION	6
B. TERMINAL DISPLAY	6
C. COMMANDS	6
<u>VIII. RADIATION CALIBRATION</u>	<u>7</u>
A. CHANGING THE DISPLAY TO THE CALIBRATE MODE	7
B. CALIBRATION, EXPONENT AND DEADTIME FACTORS	7
C. RATE MODE CALIBRATION	7
D. INTEGRATE MODE CALIBRATION	8
E. CAL FACTOR FOR INTEGRATE RANGE AND RATE RANGE	8
F. DETECTOR PLATEAU	8
<u>IX. PROGRAMMING AND MAINTENANCE</u>	<u>9</u>
A. MAINTENANCE	9
B. SETUP MENUS	10

C. ADDING AND USING ADJUST (SIMPLE WAY TO CHANGE SOME SETTINGS)	11
D. CUSTOMIZING THE MERIDIAN	12
E. FUNCTION MENUS	13
F. PROGRAMMING	14
G. CALIBRATION MENU AND DETECTOR SETUP MENU	15
H. SETTING UP A DIFFERENT DETECTOR	16
I. CUSTOM SETTINGS MENU	20
J. QUESTIONS & PROBLEMS	27
<u>I. APPENDIX A WORKSHEET</u>	<u>28</u>
<u>II. APPENDIX B SCHEMATICS</u>	<u>30</u>
<u>INDEX</u>	<u>34</u>

Specifications

A. MECHANICAL

Size overall: 8.55 in. (22 cm) W x 9.5 in. (24 cm) L x 17.5 in. (45 cm) H. Gasketed splashproof aluminum enclosure. Top panel is milled and anodized with nonerasable nomenclature. Bottom painted. LCD window is acrylic.

Weight: 20.5 lb. (9.3 kg) with batteries.

External controls: 4 pushbuttons (Power, Mode, Speaker, and Light) Power button when held down for 5 seconds resets the microprocessor.

Internal controls: 1 push-button for entry into calibrate mode.

Internal construction: Circuit board hinges for easy access. Batteries are mounted on an aluminum panel in nylon holders. ICs are socketed. All components are standard types.

B. ELECTRICAL

Detectors: Bf3 Standard, He3 available.

Display: 2 line x 20 character alphanumeric supertwist LCD with backlight. Contrast adjustable from front panel.

Audio: Built in piezo beeper at 2.4 kHz.

High voltage: Adjustable from 300 to 2000 Volts

Batteries: 6 AA cells for 100 hour life. Battery condition displayed at turn on and turn off. Low battery warning during operation. Instrument will automatically turn off when batteries are too low for proper operation. May be set for auto turn off.

Calibration and parameter storage: Data stored in permanent memory for minimum of 40 years. Batteries not required for storage.

C. OPERATIONAL

Modes: 2 modes available, Rate and Integrate, others programmable. Calibration, setup, and maintenance mode also available.

Units: Conventional and SI units.

Rate mode: Shows numeric value of rate. Updated every second. Limited to 3 significant digits. Autoranging.

Integrate mode: Shows Integrated dose. Also shows integration time. Count-down and count-up for time.

Bargraph: Moving digital pointer on background of scale markings. Updated 10 times every second. Bargraph width is 3 in (7.6 cm). Full scale markings are actively shown on the display.

D. RESPONSE

Range: 0.01 to 10,000 mrem/h.

Accuracy: Within 1% or 2 digits for count rates independent of detector. Timebase is crystal controlled.

Time constant: Dynamically set depending on count rate but has settings of short, medium and long.

Dead time correction: Corrects up to 4 times actual rate.

E. ENVIRONMENTAL

Temperature range: -20 °C to 50 °C

Humidity range: 0 to 95% non condensing. Instrument may be in taken through the condensing phase with the addition of a desiccant pack.

II. Introduction

The model 5085 Meridian is a highly functional Neutron instrument. It may of course be used in general surveying, but it will also find use in counting labs, medical applications and non technical radiation monitoring. The Meridian handles all of these tasks simply.

The standard instrument with factory settings has one menu and 4 front panel keys. Some of the features are:

- Deadtime correction
- Autorange with minimum and maximum scales.
- Ratemeter and Integrator
- Setable integration time
- Active calibration.
- Averaged reading with dynamically set time constant.
- Sealed metal case
- Detector separates from readout
- Cord wrap for detector cable

III. Quick Start

This section is a quick review of how to operate the instrument and how to change to the menu, mode and functions. Each one is discussed in detail in the individual sections.

Turn the instrument on and off by pushing the **POWER** button. The normal operation starts after the battery check display.

The light button turns the light on and off. The speaker button turns the beeper on and off. Try both of them. You will have to shield the display from room light to see the backlight, but it is very visible in the dark.

If the display does not have a bargraph on the bottom line push **MODE** to display the Function Menu. Then push the **MODE** softbutton (the button with the speaker above it) until RTE is on the line above **MODE**. Then push the **NEXT** softbutton. The display should now show mRem/h (or uSv/h if in SI units) on the top line and have a bargraph on the bottom line.

Next switch to the Integrate Mode to see what it will look like. Push **MODE** to display the Function Menu. Then push the **MODE** softbutton until **INTG** is on the line above **MODE**. Then push the **NEXT** softbutton. This is the Integrate Mode. Push the **INT** softbutton to start it running. Push it again to stop, and again to reset.

You change the time by pushing the softbutton **TIME**. The \rightarrow and \leftarrow softbuttons change the time, the **RST** softbutton resets the time to zero. Push the **OK** softbutton when the time is what you want.

The Function Menu offers other choices besides changing the Mode. Pushing **MODE** shows the Function Menu. The choices are: **LCD** for changing the LCD contrast and **TC** or Time Constant for setting the speed of the bargraph

This concludes the section on Quick Start. See the sections that follow for a detailed description on all the functions available on the Meridian.

IV. Operation

A. **TURN ON AND OFF**

The Meridian is easy to turn on, just push the **POWER** button. Pushing it once will turn the instrument on and pushing it again will turn the instrument off. The first display will show the version number of the software, 4 places of user text, and the hours remaining on the battery. Then the instrument will go into normal operation.

If the batteries are too weak it will not turn on. If it tries to turn on and immediately turns off, it may also be due to weak batteries. The instrument will automatically turn off whenever the batteries are too weak to power the instrument.


If the instrument detects a fault in the memory, it will show **FAILURE #1** in the display. If this occurs see the section on Maintenance.

The turn off display shows the hours remaining on the batteries. If the instrument has less than 8 hours, it will beep three times to indicate that the batteries should be changed.

B. **EMERGENCY RESET AND CONTRAST**

If the batteries are good and the instrument will not turn on, it is possible that the instrument is actually turning on but the contrast is set too light or dark. To do an emergency contrast setting, turn the instrument on while holding down the speaker button. Wait 2 seconds then release the button. Then hold down the speaker button if the display is too light. If the display is too dark, then hold down the light button. Continue to hold the button down until the display shows a normal contrast and the contrast menu. Then push the **NEXT** softbutton to resume normal operation.

The instrument can be reset by holding down the **POWER** button for 10 seconds or until the display blanks, then releasing it. This is a cold start for the microprocessor. It will reset the instrument which should then show the turn on display. This can be done at any time to reset the instrument and is the same as turning it off then back on.



VI. Operational

A. **DETECTOR CONNECTION**

The detector is connected to the instrument through the MHV located on the top panel.

B. **LOW BATTERY**

When the battery is low and has less than 8 hours remaining, the word **LBAT** flashes in the upper right hand corner. It flashes every 12 seconds. It does not flash in the Function Menus.

C. **BATTERY CHANGE**

When the batteries are too low as indicated on the turn on menu, or the turn off menu, then it is time to change them. The instrument uses 6 type AA "penlight" (ANSI L40 IEC LR6) cells. These can be any type of battery except lithium. (If you want to use lithium, use 3 ea. 3 volt lithium AA cells and 3 dummy AA batteries). The hours that are displayed at turn on and turn off are calculated for alkaline batteries. Carbon-zinc batteries will not give the correct time.

The batteries are located inside the instrument. Access is by removing the bottom case. To change the batteries, remove the bottom of the enclosure by twisting the twist-lock connectors on each end of the instrument counter-clockwise. This should release the bottom of the instrument. Remove it and turn the instrument over. There are the 6 AA cells. Remove the existing batteries, and replace them with new ones. Replace the bottom of the enclosure.

If the batteries have leaked into the bottom of the instrument, wash the case bottom thoroughly with soapy water, then with clear water. Dry it and replace it on the instrument. Do not wash the circuit board. The battery holders may need to be cleaned with a dampened cloth or sponge.

D. **DEADTIME CORRECTION**

The Factory settings turn on the deadtime correction in the Rate Mode, and the Integrate Mode.

VII. OPERATION OF THE RS232 OPTION

The RS232 Option sends the current display data out the serial connector for viewing on a terminal or computer running a terminal program.

A. OPERATION

The Meridian with RS232 Option is supplied with a cable with a small round connector on one end, and a rectangular DB9 connector on the other end. To hook up the cable:

1. Connect the small round connector into the jack on the right of the front panel of the Meridian. It pushes in place. To remove it, push on the black bump on the connector.
2. Connect the other end to a com port in your computer. This is usually com 1 or 2.
3. Using the Terminal or Hyperterminal program supplied with your Windows program, set your com port to 9600 Baud, 1 stop bit, 8 data bits, and no parity. Set flow control to off or none. Set it to the com port that you attached the cable.
4. Turn on the Meridian. You should see a sign-on message "MODEL 5085 MERIDIAN NEUTRON SURVEY METER" and a prompt.

B. TERMINAL DISPLAY

Typing a "?" or "/" will display the help menu shown below.

```
MODEL 5085 HELP MENU
Q   Starts/Stops 1 second data transfer for rate ranges
D   Sets discriminator
H   Sets High Voltage factor
CF  Sets the Calibration Factor: 3 digits, DP auto inserted
X.XX
CE  Sets the Calibration Exponent: 2 digits
CD  Sets the deadtime
MR  Changes mode to Rate
MC  Changes mode to CPM/S
MI  Changes mode to Integrate
MS  Changes mode to Scaler
V   Shows all variables

FOR INTEGRATE OR SCALER MODES ONLY.
S   Starts/stops/resets scaler and integrator
T   Sets time in HH:MM:SS for current mode
```

C. COMMANDS

The settings for some commands are in hex and some are in decimal. The "h" following a number indicates hex.

- Q** <ENTER> Starts and stops the data transfer in the rate range. This sends out the current level every second.
- D** <ENTER> Sets the discriminator. The range is from 0 to FFh, however the setting should be from 32h (50d) and above for this version of the instrument. The Calibration sheet will show the normal setting of the discriminator.
- H** <ENTER> Sets the high voltage. The range is from 0 to FFh. FFh is approx 2200V.
- CF** <ENTER> Sets the mantissa of the calibration factor. It is a 3 digit number and is assumed to be X.XX. Enter it without the decimal point.
- CE** <ENTER> Sets the calibration factor exponent. It is a 2 digit number. Type the number first, then it prompts for the sign.
- CD** <ENTER> Sets the deadtime. It is a decimal number from 0 to 255. Always enter three digits. A deadtime of 5 would be entered as 005.
- MR** <ENTER> Changes to the rate range if it is enabled.
- MC** <ENTER> Changes to the cpm (or cps if in SI units) range if it is enabled.
- MI** <ENTER> Changes to the integrate range if it is enabled.
- MS** <ENTER> Changes to the scaler if it is enabled.
- V** <ENTER> Shows all of the variables and the factors for the current range.
- S** <ENTER> Starts stops and resets the integrate range and scaler.
- T** <ENTER> Sets the current time in the integrate range and scaler. It prompts for the hours, minutes and seconds. If you just push <ENTER> it will enter a 0.

CAUTION: Changing the calibration factors, deadtime, discriminator or high voltage will change the calibration of the instrument.

VIII. Radiation Calibration

The instrument is calibrated digitally. There are no trimmers to adjust. The values that adjust the calibration are stored in EEPROM memory for 40 years.

There are two adjustments for each detector that effect the calibration. The instrument is adjusted by changing the calibration factor with exponent, and the deadtime. The Rate Mode and the Integrate Mode need to be calibrated. Changing The Display To Calibrate Mode

A. CHANGING THE DISPLAY TO THE CALIBRATE MODE

1. Turn on the instrument with the **MODE** button pushed down. If this does not result in the words **Calibration *1** in the display, then the Front Panel Calibration Adjust has been disabled and it is necessary to use the internal one. The internal Calibration Adjust button is located through a small hole between the two battery holders. Push it while turning the instrument on. The words **Calibration *1** should be on the display.
2. Push the **OK** softbutton and the Meridian will resume normal operation with the radiation value on the top line, and the calibration factor on the bottom line.
3. The softbuttons change the numeric value in the bottom line of the display. The \rightarrow Softbutton will move the cursor over 1 place and the $-$ softbutton will increase the value of the number positioned over the cursor. Using the two buttons, you can change the value of the displayed item in the bottom line. The radiation level in the top line will change along with the changes in the bottom line.
4. In the Rate mode, the item on the bottom line can be changed by pushing **MODE** then the \rightarrow or $-$ softbuttons until the item description is what you want to change or do. Then push the **MODE** button to return to the calibration. If you do not push the \rightarrow or $-$ softbuttons the normal function menus will be displayed when you push the **MODE** button.
5. In the Integrate Range the softbuttons are already in use. Pushing **MODE** repeatedly will show the factor followed by the normal Function Menu. The factors is adjusted just like the ones in the Rate Mode.
6. There are 3 adjustments to be made, the Calibration Factor, the Exponent and the Deadtime. The Calibration Factor and Exponent form a number that determines the value on the display. They should be thought of as one number in exponential form. Changing the Calibration Factor and Exponent changes the value on the display at all doserates. Increasing the number will increase all the readings in that Mode. Decreasing it will decrease the reading.

The Deadtime corrects for deadtime losses that occur in all pulsed detectors. The Deadtime number will effect the readings at high count rates. At low count rates, the change is insignificant.

0	mRem/h	1000
FACTOR	1.00E-04	\rightarrow -

CALIBRATE DISPLAY

B. CALIBRATION, EXPONENT AND DEADTIME FACTORS

The Calibration, Exponent and Deadtime Factors are all used in the Calibration of the instrument. The Calibration and Exponent are in reality one number. This number is used to increase and decrease the value of the calibration. If the calibration is 10% too low then it is necessary to increase the Calibration Factor 10%.

The combination of Calibration Factor and Exponent are, in reality, a number in scientific notation. A Calibration Factor of 6.35 and an exponent of 2 is in scientific notation 6.35×10^2 . The Calibration Factor should be set in the range of 1.00 to 9.99. Raise and lower the exponent to compensate if it is necessary to go beyond these limits. For example, if the Calibration Factor is 9.5 and the Exponent is 3 then an increase of 10% would be $9.5 \times 1.1 = 10.45$. This is not in the range of 1.00 to 9.99 so decrease the Calibration Factor by 10 and add one to the exponent which would be 1.04 with an exponent of 4. The same is true of the other direction. If the Calibration Factor is 1.24 and the Exponent is 3 and it is necessary to decrease it by 30% then 1.24 would be reduced to .868. This is below 1.00 so decrease the exponent by 1 to 2 and increase the Calibration Factor by 10 to 8.68.

The range of the Exponent is from -40 to +40. In reality it should never be necessary to set it over the range of -8 to +8.

The deadtime is in units of microseconds. It should be close to the value specified by the manufacturer of the detector. Its value is from 0 to 999 μ S. It will be adjusted during the calibration.

C. RATE MODE CALIBRATION

1. Turn on the instrument by pushing the **POWER** button. If the units of mRem/h are not displayed in the display, then push **MODE**. Push the **MOD** softbutton until **RATE** is displayed above **MOD**. Then push the **NEXT** softbutton. MRem/h should now be the units in the display. Enter into the Calibrate mode as discussed above in Changing The Display To The Calibrate Mode.
2. Change to the Rate Mode. If the Rate Mode is not displayed, then push **MODE**. Repeatedly push the **MOD** softbutton until **RTE** is displayed above **MOD**. Then push the **NXT** softbutton twice. The Rate Units should now be in the display.
3. Expose the detector to a radiation field that is at the lower end of the sensitivity of the detector. With a Bf3 Detector (Normal 5085) this is 10 to 50 mRem/h. Change the Calibration Factor and Exponent until the reading is correct.

4. Expose the detector to a field that is at the upper end of the sensitivity of the detector. With a Bf3 Detector (Normal 5085) this is 5085 to 10,000 mRem/h. Adjust the Deadtime until the reading is correct.
5. Repeat steps 3 and 4 until both settings are correct.
6. Expose each range/decade at 20% and 80% of full scale. Note the readings on the calibration report.
7. Turn the instrument off by pushing the POWER button when finished.

D. INTEGRATE MODE CALIBRATION

1. Enter into the Calibrate mode as discussed above in Changing The Display To Calibrate Mode.
2. Change to the Integrate Mode. If the Integrate Mode is not displayed, then push **MODE**. Repeatedly push the **MODE** softbutton until **INT** is displayed above **MODE**. Then push the **NEXT** softbutton twice. The Integrate range should now be in the display. Read section E below to determine if you want to use the Rate Range Calibration Factor to set the Integrate range Calibration Factor.
3. Expose the detector to a known dose in a radiation field that is at the lower end of the sensitivity of the detector.
4. Change the Calibration Factor and Exponent. Repeat step 3 until the reading is correct.
5. Expose two lower ranges at 80% of full scale. Note the readings on the calibration report. (The deadtime correction is already set in the Rate Mode.)
6. Turn the instrument off by pushing the POWER button when finished.

E. CAL FACTOR FOR INTEGRATE RANGE AND RATE RANGE

The rate range calibration factor can be used to set the integrate range. If you are satisfied with the rate range calibration you may be able to use the rate range calibration factor as the basis for calculating the integrate range calibration factor. You may also choose to calibrate them independently.

If the integrate range is in the same prefix-units as the rate range then the rate range Calibration Factor can be used in calculating the integrate range Calibration Factor. If the rate range is in mR/h and the integrate range in mR then they are considered to have the same units.


Divide the rate range Calibration Factor with Exponent by 60 if the internal timebase is in CPM (Conventional Units) and by 3600 if the internal timebase is in CPS (SI units). Use this new calibration Factor and Exponent for the integrate range. If you use this Calibration Factor, then the rate range and integrate range will have the same calibration.

F. DETECTOR PLATEAU

The High voltage is usually set by either using the recommended voltage from the manufacturer or by plotting the plateau. All new instruments have been adjusted for operation on the plateau. The voltage is supplied on the calibration sheet. To plot the plateau:

1. Turn on the instrument with the **MODE** button pushed down. If this does not result in the words **Calibration *1** in the display, then the Front Panel Calibration Adjust has been disabled and it is necessary to use the internal one. The internal Calibration Adjust button is located through a small hole between the two battery holders. Push it while turning the instrument on. The words **Calibration *1** should be on the display.
2. Push the - softbutton until **Det Setup *2** is in the display. Then push the **OK** softbutton and the Meridian will resume normal operation with the radiation value on the top line, and the calibration factor on the bottom line.
3. Push the **MODE** button and then use the $\bar{\sim}$ or - softbuttons until the words High Voltage shows in the display. Then push the **OK** softbutton. The instrument will resume normal operation with the High Voltage on the bottom line.
4. Expose the detector in a fixed geometry to a medium intensity radiation source.
5. If the instrument is reading a value other than zero, slowly lower the high voltage using the $\bar{\sim}$ or - softbuttons until the instrument reads zero. If the instrument is reading zero, raise the high voltage until it reads a low value.
6. Raise the high voltage in uniform steps of 50 volts. At each step note the radiation level. **Do not go above the maximum voltage for the detector.** Plot the High voltage vs. reading on a graph.

Adjust the high voltage in the instrument to the value that corresponds to midway on the plateau. If there is no upswing, then adjust it above the knee.



GRAPH OF HIGH VOLTAGE VS COUNTS

IX. PROGRAMMING AND MAINTENANCE

The Programming and Maintenance section of the manual contains items that are outside the scope of normal operation and calibration. You will be interested in this section if you want to customize the Meridian, use a different detector, or troubleshoot the electronics.

A. MAINTENANCE

1. Maintenance Mode

This mode is useful for checking the operation of the instrument when it is needed for repair. Each menu item is used for checking, or changing some electrical part of the instrument.

If you do decide to change the settings with this menu, remember to disconnect the detector in case the high voltage changes. This mode does not change any stored value. The maintenance mode is reached through the following:

1. Turn on the instrument with the **MODE** button pushed down. If this does not result in the words **Calibration *1** in the display then the Front Panel Calibration Adjust has been disabled and it is necessary to use the internal one. The internal Calibration Adjust button is located through a small hole between the two battery holders in the battery compartment. Push on this button while turning the instrument on. The words **Calibration *1** should be on the display.
2. Advance the menus using the - or $\bar{\text{~}}$ softbutton until the display shows **Maintenance *8**. Then push **OK**. You are now in the Maintenance Mode.

a) Maintenance Mode Display Description

The Maintenance Mode display shows the selected item in the top left, the factor (in hex) associated with the item in the middle, and the counts from the detector for .1 second on the right. Pushing the **NEXT** softbutton on the bottom line will change between the items. The * softbutton will go back to the Setup Menus. The - or $\bar{\text{~}}$ softbuttons change the factor.

HV Changes the high voltage by varying the output voltage of pin 18 of U12 (HVDAC). This is the reference voltage of the HV section.

DISCR Changes the Discriminator by varying the output of pin 5 on U12 (DISCR). This is the reference voltage of U15.

SAT Measures the saturation voltage on the HV transformer.

LTE Turns the light on and off.

BUZ Turns the buzzer on and off. Needs an external input to cause the beeper to beep.

DIV Changes the divider to the buzzer.

BAT Shows the battery voltage.

MONITOR Switches to the monitor program to test and examine memory. Needs RS232 connection to work. To recover from this test, push the power button down for 10 seconds to reset the instrument or on the RS232 connection type G0.

2. High Voltage Calibration

The high voltage displays on the Meridian are actually measured rather than just calculated. This measurement system may need calibration. Connect a high voltage high impedance meter with >10,000 megohm input resistance to the detector connector on the front panel. The meter should be capable of measuring 2200 Volts DC.

1. Turn the instrument on in the Setup Menu and change it to the **HV Calibrate *6** Menu. Press ok to change into the HV calibrate display.
2. Measure the high voltage with the external voltmeter.
3. Using the \uparrow and \downarrow softbuttons change the **Cal:** number until the **HV:** is as close as possible to the measured high voltage.
4. Push the **ok** softbutton to save the value. Push the **POWER** button if you do not want to change the calibration.

3. Failure in Display

If the display says FAILURE, then the EEPROM has failed. This may mean that it is corrupted or that it is not working. In any case you should try to reprogram it which may preserve many of the settings.

1. Turn the instrument on after the display shows **Failure #1**, push the internal **CAL** button on the back of the main circuit board. It is accessible through a small hole between the battery holders. The display will change to the Setup Menu.
2. Advance the menus using the - or $\bar{\text{~}}$ softbutton until the displays shows the **Custom Set *3**. Then push **OK**. Push the **POWER** button to change the cursor to the Data. Use the \rightarrow and - softbuttons to change the Data to 26. Then push the **POWER** button then the **MODE** button twice.
3. If the display shows a normal turn on, then the EEPROM was only corrupted a little, and it would be wise to check the calibration and operation of the instrument. If it shows a **Failure #1**, then the EEPROM is defective and should be replaced.

4. Installing a New EEPROM

When installing a new EEPROM it is necessary to program it to the default values. It will show **Failure #1** in the display until it is programmed.

1. Turn the instrument on after the display shows **Failure #1**, push the internal **CAL** button on the back of the main circuit board. It is accessible through a small hole between the battery holders. The display will change to the Setup Menu.
2. Advance the menus using the - or $\bar{\text{~}}$ softbutton until the display shows the **Factory Set *9**. Then push **OK**, answer the question on CPM (answer no if you want CPS or SI units), and then Yes to **Are you sure?**. It will take 30 seconds to program the entire EEPROM.

3. After it is done programming, push the Mode button to resume normal operation.
4. Check the new EEPROM by turning the instrument on and off. If it turns on without the failure warning, then it has been programmed.
5. The instrument will now need to be completely recalibrated.

5. Factory Settings

To program the instrument with the factory settings:

1. Turn on the instrument with the **MODE** button pushed down. If this does not result in the words **Calibration *1** in the display then the Front Panel Calibration Adjust has been disabled and it is necessary to use the internal one. The internal Calibration Adjust button is located through a small hole between the two battery holders in the battery compartment. Push on this button while turning the instrument on. The words **Calibration *1** should be on the display.
2. Advance the menu using the - or $\bar{\text{~}}$ softbutton until the display shows the **Factory Set *9**. Then push **OK**, answer the question on CPM (answer no if you want CPS or SI units), and then Yes to **Are you sure?**. It will take 30 seconds to program the entire EEPROM.
3. After it is done programming, push the Mode button to resume normal operation.
4. The instrument will now need to be completely recalibrated. The calibration sheet that was shipped with the instrument contains the calibration factors that can be used to reprogram the instrument.

B. SETUP MENUS

The Setup Menus are special menus that are different than the normal operation of the instrument. These menus allow adjustment and setting of all the variables in the instrument. These include for example, the button definitions, the calibration values, the operating displays, the detector settings and the defaults.

1. Accessing The Setup Menus

These menus are not available in any of the normal operating modes. There are 2 ways to enter into the Setup Menus. The first method, which is always available is to push a switch on the inside of the case. The second method is through the front panel, but it may be user disabled. The two methods are:

a) METHOD 1 INTERNAL BUTTON

1. If the instrument is on, turn it off.
2. Remove the battery cover on the back of the display box.
3. Between the two battery holders is a small hole. Push the pushbutton behind this hole while you are turning on the instrument. Use a paperclip or any other small item that will fit through the hole. The display should show the first Setup Menu.

b) METHOD 2 EXTERNAL BUTTON

1. If the instrument is on, turn it off.
2. Push the **MODE** button and hold it down, then push the **POWER** button. Continue to hold down the **MODE** button until the Setup Menu appears. If the regular turn on menu appears instead, then the front panel has been disabled and it is necessary to use the internal button in Method 1

2. Scrolling Through The Setup Menus

The Setup Menu is the main menu that directs you to several other menus or operations. The top line of the display shows the selection that is offered followed by a number. Each item is numbered and has a * before the number to identify it. The bottom line contains the \uparrow softbutton and \downarrow softbutton and the **ok** softbutton. Push the \uparrow softbutton to go to the next item on the list. Push the \downarrow softbutton to go to the previous item on the list. When you have the selection that you want, push the **ok** softbutton. The screen will then change to the new item.

3. * Setup Menu Selection

The following is a list of menu selections in Setup. Each selection has a * followed by a selection number to make it easier to find. If a Softbutton is labeled * this means that pushing it will get back to this menu.

The * menu selections and their definitions are listed below.

a) Calibrate *1

This is the menu to change the calibration of the instrument. Please see the Calibration and Detector Setup Menu for a full understanding of how to use this menu. Also see the section on Calibration to understand the settings. It is used to change the following: Calibration Factor, Exponent, and Deadtime.

b) Detector Setup *2

This is the menu to change both the calibration of the instrument and the setup of the detector. Please see the section on Detector Setup Menu for a complete description of this menu. It is used to change the following: Calibration Factor, Exponent, Deadtime in/out, Deadtime, High Voltage, Saturation, Discriminator, Range High Limit, Range Low Limit, Units, Prefix, and Timebase

c) Custom Settings *3

This is the menu to change individual memory locations in the EEPROM that in turn program the instrument. All of the instrument variables are stored in the EEPROM. This menu allows complete access to all the possible changes and setups in the instrument. It allows you to change everything changeable about the instrument. Please see the section on Custom Settings for a complete description of this menu.

d) Front Panel *4

The Calibration and Setup Menus can be reached through the front panel or internally. This menu changes the access from the front panel. It also turns on and off the **Adjust Menu** for the Quick-keys. The choices are: **Front panel on/off, Adjust on/off** for all modes or for just the scaler. See the Operational section for more information on Adjust. If you want to be able to calibrate the instrument from the front panel push yes. If you want to be able to access the Adjust from all modes then push yes to the next question, and if you want to

adjust only in the scaler mode push yes to the next question and no to the previous question.

e) Automatic Turn Off *5

The instrument has the capability to automatically turn itself off if it is not in use. This menu turns that capability on and off. If you want the instrument to automatically turn off then push yes. This will automatically turn it off after the time that is programmed into the instrument. The default value is 108 minutes. See and power time in Custom Setting section for more information on setting the value..

f) High Voltage Calibrate *6

The high voltage is displayed in several menus. This is a measured high voltage. This menu adjusts the calibration of the high voltage measurement so the value will be displayed correctly. It does not change the actual voltage of the high voltage. See the section on Maintenance for more information.

g) High Voltage Setting *7

This menu will adjust the setting of the high voltage. It allows you to preset the value of the high voltage for a particular detector without having to go into any other Menu. The top line of the display shows, after the **HV:**, the actual measured value of the high voltage. The number after the **Fac:** is the high voltage factor which is a number that the instrument uses to set the high voltage. It is also the number that is put into the memory to represent that high voltage. Select which detector you want to change using the **det** softbutton. The choices are detector 1, 2 or 3. Use the **↑** or **-** softbuttons to change the value of the factor which in turn raises and lowers the actual high voltage. Save the data by pushing the **sav** softbutton after which the menu will change back to the ***** or Setup Menu. To change another detector, just push the **ok** softbutton.

h) Maintenance *8

This menu will allow adjustment of several parameters without changing their permanent values. The adjustments include high voltage, discriminator, saturation, light, beeper, divisor, and battery. In addition it will allow the use of a monitor program. See the section on Maintenance for more information.

i) Factory Setting *9

This setting is used at the factory to preset the instrument. The settings are the same as the **Standard Instrument Preset** combined with the Bf3 detector. In addition it sets up and programs all the other parameters such as contrast, user characters, and current mode to start the instrument operation off properly. See the section on Factory Settings in Maintenance.

This is also the menu to change the internal timebase from CPM to CPS. Internally the instrument calculates the basic rates from counts per minute or counts per second. This control changes that setting. If this setting is in CPS then any presets for Preset Instrument or Preset Detector will be in SI units. If you want CPM, answer yes to the question **CPM Timebase?**. For more information see the section on Programming: Internal Timebase.

**C. ADDING AND USING ADJUST
(Simple way to change some settings)**

Adjust is a method of changing the settings for the detector without using the Setup Menus. It is designed to allow quick field adjustments without cumbersome button pushing. The Adjust Menu is accessed by pushing the ***** and **D** buttons at the same time. If adjust is enabled, the Adjust Menu will be displayed. If it is disabled, it can be turned on by Adjust can be set to operate in either all modes, or just the scaler mode.

Adjust allows simple adjustment of the High Voltage, Discriminator, Window, Window in/out and Gain. This is an interactive adjustment that is made while looking at the count rate.

a) Turning Adjust On And Off

Adjust is turned on and off in the Setup Menu and is under **Front Panel *7**. It has 2 choices, the first is for all modes, and the second is for just the scaler mode.

b) Using Adjust

The display has the function name in the upper left hand, the value of the function in the center of the display, and the count rate display in the upper right. The Count rate display is the number of counts in 0.1 second. The **NXT** softbutton changes to the next function, and the **↑** and **-** softbuttons will increment or decrement the value of the function. Hold them down until the function is at the desired level. The Mode button will return to normal operation.

HV or High voltage will change the High Voltage. The display number will bounce about ± 30 volts. Be careful not to increase the high voltage above the limit of the detector.

DISCR or Discriminator is the setting for the discriminator. It can be set from 0 to 255 but is linear from 0 to 100.

D. CUSTOMIZING THE MERIDIAN

The Meridian may be customized by changing the variables. The operation of the instrument is very programmable and is based on the Cypher Survey Meter which is a very programmable instrument. The section on the Custom Menu describes each of the variables. The Description of Custom Setting Menu shows all the possible settings for the Meridian. We offer the following tips and suggestions on how to change the instrument to meet your particular needs.

1. Buttons

Probably the most useful changes to the instrument revolve around the buttons. This includes both the Quick-keys and the Function Menus. They both can be modified to meet your needs.

The Quick-keys are the buttons that are on the right hand side of the panel and are active during CPM/S, Rate and User Modes. These are also referred to as the * and D Quick-keys. In the Meridian the quickkeys are predefined as the light and speaker buttons and they are factory set to Beeper and Light, which are probably the most generic uses of the controls on a survey meter. There are 7 other choices that are available. If you do not need the light or beeper, then you may consider using either button for either the Range Hold, Hold or contrast. The other options are listed under the * or Δ Buttons in Custom Settings.

There is 1 Function Menu with the factory settings. If you need more capability, such as range hold, you could change up to 3 Function Menus.

The location of the functions within the Function Menu can also be changed. Each of the three locations above the three right hand buttons is available for any of the functions. If you are left handed and use the MODE button frequently, consider moving it to the left hand side of the instrument. (Changing location 18 from 5 to 10 and location 20 from 10 to 5 in the Custom Menu will swap the MOD and RH^H.) We usually put the most used functions on the first menu.

2. Display

The display is the other part of the instrument that can be customized to fit your needs. Particularly important is the full scale range of the bargraph. We have it set at 10 for the factory settings, however many survey meters have 50, 500, and 5085 CPM full scale primarily to put background counts from pancake GM detectors farther up the scale. If you wanted to emulate one of these meters, change the Bargraph Type to 2 in Custom Setup. There also is a 2.5, 25, 250 and 2500 full scale available.

If you are using the instrument in areas where the bargraph may confuse some people, you can turn it off by setting the bargraph to off in Display Configuration in the Custom Setup Menu. Just read the current value, look at the table and find out the current settings. Then look for the same settings but with the bargraph off and change the data to the new value.

We also offer the choice of normal or inverted display with the bargraph on top. This may be useful for some applications where you need 2 different bargraph scales, perhaps one a log scale for mR/h and one a linear scale for CPM.

The Range Up and Down Time allow the instrument to dwell on a range without going up or down a range quickly. The Range Up Time would be useful for

contamination surveying near background where there are hot spots. It would keep the range from going to the next higher range quickly. It may be set to 2 or 3 seconds. Likewise you may be using the detector in high radiation levels and not want it to range down during a momentary dip in radiation. In this case increasing the Range Down Time would be useful. Set both of these in the Custom Setting Menu.

3. Modes

The modes can be turned on or off. This allows the instrument to function in whatever capacity you want. If you do not need a scaler or an integrate range, turn them off using the Mode Lockout in the Custom Settings. There is also a User Mode that can be programmed in any rate units you want. Use the Mode Lockout in the Custom Settings Mode to turn on this mode. Then program it in the Setting Up a New Detector section for the units, prefix, etc., just the same as the rate range.

The CPM/S range can also be changed into any units. It does not have to be used for CPM/S

4. Internal Time Base

The internal timebase of the Meridian can be in Counts per Minute or in Counts per Second. In general, CPM is used with conventional units, and CPS is used with SI units. See the section on Programming: Internal Timebase for more information.

5. Detector

There are a maximum of 3 detectors that can be used with the Meridian if each needs its own set of settings. Of course, any number can be used with the same settings. For example, many GM detectors use the same high voltage and all should be used on the CPM/S range. However all would not read correctly with the Rate Range. To add detectors you will need to either make a DET Function Menu or Soft Button. In addition you will need to set the Detector Max. See section above on Buttons.

6. Printed Bargraph scale

The printed bargraph scale is between the window and the display. It contains the numbers for the scale for the bargraph. New scales are available from the HPI. Various bargraphs are available or you can make your own with a word processor. To install a scale:

1. Remove the bottom case from the instrument.
2. Remove the two screws that hold the front of the circuit board to the spacers. The circuit board with batteries should fold away from the front panel.
3. Remove the old scale; it is glued in place. Be careful not to scratch the display.

Cut out the new scale using scissors. Add a small piece double stick tape to the back of the scale. Replace the scale in the instrument. Replace the screws and bottom case.

E. FUNCTION MENUS

The following is a list of all of the function menus. The first three are programmed in the standard instrument. Additional menus are available by programming using the Customs Setting Mode.

1. LTE Backlight on the display

This controls the backlight on the display. The backlight is not very visible in daylight but is very visible in low light. The choices are:

- OFF** The backlight is off.
- TME** The backlight is timed. This turns the backlight on for 25 seconds. After the 25 seconds it will automatically turn itself off. The time is stopped when in the Function Menus.
- ON** This will turn on the backlight until it is turned off.

2. MOD Mode

The mode controls which mode the instrument is operating in. The previous section describes each mode in detail. The choices are:

- CPM** This is the CPM Mode.
- RTE** This is the Rate Mode.
- INT** This is the Integrate Mode.
- SCL** This is the Scaler Mode
- USR** User Mode (not factory installed).

3. TC Time Constant

The Time constant controls how fast the bargraph will move to a new value and how fast the digital display will home in on a new value. It does not work in the Integrate or Scaler Modes. The instrument automatically adjusts the time constant depending on the level of the radiation. It is slow on low rates, and fast on high rates. The Time Constant setting modifies these automatic setting to be slower or faster. The choices for the Time Constant are:

- SLO** The Time Constant is slow.
- MED** The Time Constant is medium.
- FST** The Time Constant is fast.

4. RH^H Range Hold

Range hold will keep the CPM Mode and the Rate Mode range in the same range; thus keeping it from going up or down a range. It is useful when surveying for low count rates when you do not want to wait for the instrument to range up to a higher range for a hot spot. A small ^H will appear on the top right hand side of the display indicating the Range Hold is in effect. The choices for the Range Hold are:

- OFF** Range Hold is turned off.
- HLD** Range Hold is turned on and the instrument will not range up or down a range. The ^H in the display turns on.

5. LCD Liquid Crystal Display Contrast Setting

The LCD controls the contrast of the display. There is only one choice and it is **SET**. Pushing it will change to a new display. The best setting is as dark as possible before the squares show. The choices of this menu are:

- LT** To lighten: push and hold down.
- DK** To darken: push and hold down
- NXT** When the contrast is correct, push this button.

6. BUZ Beeper Control

This controls the beeper. The beeper has 2 functions. In the CPM Mode or Rate Mode the beeper will, if turned on, beep on every input pulse. In the Integrate Mode or Scaler Mode, the beeper will, if turned on, beep when the timer counts down to zero to signal that the counting is finished. The choices are:

- OFF** The beeper is off.
- SFT** The beeper is turned on and the loudness is soft.
- ON** The beeper is turned on and the loudness is set to the highest level.

If the beeper is set to **SFT** then that is the loudness for the beeper. The front panel * Softkey, used for beeper on/off, will only turn the beeper on to the loudness set in the Function Menu.

7. DTM Deadtime

Deadtime correction is used to compensate for the loss of counts at high count rates. The actual deadtime calibration and constant is set in the instrument at the time of calibration. The choices are:

- IN** This mode has deadtime correction
- OUT** This mode has no deadtime correction.

The deadtime correction is turned on and off independently for each mode.

8. DET Detector

The instrument will accept 3 detectors. This controls which set of detector constants are in effect. This effects the calibration, high voltage, deadtime, display, etc. The choices are:

- 1** Use the constants for Detector 1
- 2** Use the constants for Detector 2
- 3** Use the constants for Detector 3

The instrument will prompt the user to remove the old detector and to install the new detector.

9. HLD Hold

This puts the instrument on hold. **HOLD** is displayed on the top right hand corner of the display. The numeric number is held, but the bargraph continues to function. The choices are:

- ON** Freezes the numeric display
- OFF** Normal operation

10. DIV Divider for Beeper

The counts from the detector can be divided by 1,8,64 or 2048 before they are sent to the beeper. This is useful where the beeper may otherwise be saturated or sound like it is on continuously. The choices are:

- 1** Counts
- 8** Counts
- 64** Counts
- 2K** Counts

11. CAL Calibrate Mode

This mode is used to put the instrument into the Calibrate Mode. See the section on Calibrate Mode for more information. The choices are:

- OFF** Normal operation
- ON** Instrument in Calibrate Mode

F. PROGRAMMING

The following sections discuss programming the instrument. It is important to understand the setup of the instrument before actually performing it.

1. Instrument and Detector Settings

There are 2 basic kinds of settings in the Meridian. The first is the Instrument Settings. These are settings that effect the operation of the instrument. This includes the display and the buttons. The other type of setting is the Detector Setting. These effect the operation of the detector and include the calibration data, high voltage setting and discriminator.

2. Programming the Meridian

The Meridian is highly programmable. There are many different items about its operation that can be changed. There are 4 basic ways to program the instrument.

1. Use the factory settings. This is the simplest way. The instrument is setup with all the important operating parameters and settings. It takes no time
2. Use the Custom Settings menu and configure the instrument to your exact liking. This is the hardest way of programming and takes some understanding of the instrument as well as some time. It will result in an instrument tailored to your application or to your specifications.

3. Instrument and Detector Variables

The Setup Menu will change the variables inside the instrument. These variables control the function of the instrument. There are several types:

1. Variables that change the instrument rather than the detector and are considered part of the instrument. For example, the beeper on/off, the full scale bargraph, and the button definitions.
2. Variables that change with Detector 1, 2 or 3. These fall into two groups:
 1. Those that change with the Mode such as the Calibration, the Units, the Timebase, and the Bargraph type.
 2. Those that do not change with the Mode and are considered part of the detector. Examples are the High Voltage, The Discriminator, and the Deadtime.

4. Internal Timebase

The Meridian has two choices for an internal timebase: CPM (Counts Per Minute) or CPS (Counts Per Second). This changes the basic units that the instrument works in internally. It actually calculates the values in .1 CPS or .01 CPM.

If it is set to CPM in the Factory Setup menus, the instrument will be in conventional units and the rate range will probably read in mRem/h. If it is set to CPS then the instrument will be in SI units.

The CPM or CPS ranges have their own calibration and can be programmed in any units desired. It is designed to be used with CPM or CPS and that is the nomenclature in the Function Menu. If the instrument is in CPM and the Calibration Factor and Units for that range are changed to read in CPS instead of CPM, then the reading will not be exactly correct. The Calibration Factor has only 3 places of accuracy. Thus 100 CPS may read only 99 CPS.

One of the choices with the **MODE** softbutton in the Function Menu during normal operation is CPM. If you want this to be CPS then you must choose the CPS internal timebase. If you want it to be CPM then you must choose the CPM internal timebase. Changing this will also change the calibration of the Rate Range, the Integrate Range, and the User Range (if used). This is because these rely on the internal timebase for their calculations to make the CPM or CPS range read correctly.

There are several reasons to choose CPM or CPS:

1. To make the MOD softbutton selection of CPM or CPS
2. To calibrate the Rate, Integrate and User Ranges in units of CPM or CPS.
3. To make the CPM or CPS range read correctly with a Calibration of 1.00.

To change the internal timebase, use the Setup Menu item , **CPM/CPS/SI *6**; see the section on Setup Menus form more information.

G. CALIBRATION MENU AND DETECTOR SETUP MENU

The Calibration Menu and the Detector Menu allow interactive changes to be made to the instrument. This permits changing many settings or variables while looking at an operating instrument. The Calibration Menu is used in changing the calibration of the instrument during routine calibrations. The Detector Setup Menu is used for changing the settings, variables and parameters when, adding a new detector or changing an existing detector.

The two modes function exactly the same except that the Calibration Mode sets only the Calibration Factor, Exponent and the Deadtime while the Detector Setup Mode sets the Calibration Factor, Exponent, Deadtime in/out, Deadtime, High Voltage, Saturation, Window in/out, Window, Discriminator, Gain, Range High Limit, Range Low Limit, Units, Prefix, and Timebase.

The Calibration and the Detector Setup Menus will change the parameters specific to the instrument and to the detector. Some of the variables are specific to the instrument and detector and some are specific to only the detector. Changing the Range High Limit will change the values for the selected Mode for that detector. If the current mode is the Rate Mode and detector 1 is the current detector, then only the Rate mode for detector 1 will be changed. Likewise changing the high voltage while detector 1 is selected will change the high voltage only on detector 1.

The Calibration Factor, Exponent, Range Hi and Low Limit, Units, Prefix and Timebase are all Mode and Detector specific. The High Voltage, Deadtime, Saturation, Window, Discriminator and Gain are only detector specific and will not change with mode.

The following describes how to enter into the Calibration Mode or the Detector Setup Mode using the Calibration and Detector Setup Menus.

1. Turn on the instrument with the **MODE** button pushed down. If this does not result in the words **Calibration *1** in the display then the Front Panel Calibration Adjust has been disabled and it is necessary to use the internal one. The internal Calibration Adjust button is located through a small hole between the two battery holders in the battery compartment. Push on this button while turning the instrument on. The words **Calibration *1** should be on the display.
2. If you want the Calibration Mode Push the **OK** softbutton. If you want the Detector Setup Mode, then push the - softbutton until **DET SETUP *2** is in the display, then push the **OK** softbutton. The Meridian will resume normal operation with the count rate value on the top line, and the calibration factor on the bottom line.
3. The softbuttons change the numeric value in the bottom line of the display. The → Softbutton will move the cursor over 1 place and the - softbutton will increase the value of the number positioned over the cursor. Using the two buttons, you can change the value of the displayed item in the bottom line. The value in the top line will change along with the new value in the bottom line.
4. In the Rate and CPM modes, the item on the bottom line can be changed by pushing **MODE** then the ~ or - softbuttons until the item description is what you want to change or do. Then push the **MODE** button to return to the

calibration. If you do not push the ~ or - softbuttons the normal function menus will be displayed when you push the **MODE** button.

5. In the Integrate Range pushing **MODE** repeatedly will show the factors followed by the normal Function Menus. These factors are adjusted just like the ones in the CPM and Rate Modes.
6. After changing the items to the values that you want, you can either turn the instrument off or select Norm Operation from the choice of setup menu items.

H. **SETTING UP A DIFFERENT DETECTOR**

The detector is changed to a different type than the Meridian was ordered with, it is necessary to configure the instrument to operate properly with the new detector. This section discusses the procedures to change the current settings for the new detector.

1. **General**

The instrument is modified to accept the new detector by changing several parameters included in the list below. Some of these must be changed. Some may be left in the default values. The items marked with a * are accessible from the Detector Setup Menu.

1. Bargraph type
2. Calibration Factor and Exponent *
3. Deadtime *
4. Discriminator *
5. Display Type
6. High Voltage *
7. Inverted/normal display
8. Modes for the detector
9. Prefix, *
10. Range hi/low limit *
11. Range Up/down time
12. Saturation (if installed)
13. Time constant
14. Timebase for each mode
15. Units *

The units, prefix and timebase that are selected for the display are only displayed. These values do not directly change the calibration. Changing the prefix from m to μ will not change the sensitivity of the instrument. It will only change the prefix on the display. The numbers on the display will remain the same. To change the sensitivity of the instrument it is necessary to change the Calibration Factor and Exponent.

A good method of understanding the setup of a detector is to think of a traditional survey instrument with a meter. The scale behind the meter, the range switch and the calibration adjustment screwdriver adjust set the instrument sensitivity. The scale could be removed and replaced. The new scale could have very different units. That in itself would not calibrate the instrument, you would still have to change the calibration adjustment with a screwdriver to obtain a correct reading. The Meridian is very similar. The Units, Prefix and Timebase are just like the printed scale. Changing them will not change the reading. It still will have to be adjusted with the Calibration Factor and Exponent which can be thought of as the screwdriver adjust.

The big difference between the Meridian and a traditional instrument is that the Meridian will automatically select the next higher or lower prefix when it needs to change ranges rather than relying on the range switch.

2. **User Mode**

The User Mode is programmed just like the Rate Mode, except it is called **USR** in the MOD function menu. To turn it on, use the Mode Lockout location in the Custom Settings Menu.

3. **Determining The Different Settings**

The Calibration Factor, Exponent, Prefix, Units, Timebase, and Range limits all need to be calculated for each detector. The high voltage, discriminator, gain and saturation also need to be determined. Use the Detector Worksheet in the Appendix as a guide to this operation. It is a good idea to determine the settings that you want to use for the detector before programming the Meridian

We recommend changing the Calibration Factor and Exponent of only the rate and integrate ranges. The Calibration of the CPM or CPS range can be changed but it may be confusing to a user and difficult in calibration. However it may be changed if necessary. The scaler does not have a calibration. In the following descriptions we will use a GM Pancake Detector as an example, even if it is not the same detector as supplied with the instrument.

a) **Basic Detector Information**

(1) **Detector 1, 2 or 3**

The Meridian can change between detector 1, 2 or 3. This is done using the Function Menus. The Detector that is in use, or selected, is the detector whose variables will be changed. If there is no DET function in the Function Menus then there is only one detector, detector #1.

(2) **CPM or CPS Internal Timebase**

Turn the instrument on and look at the first word on the display. If it is **HPI** then the instrument has the internal timebase set to CPM, If it is **HPIs**, then the internal timebase is in CPS. To change the timebase see the section on Programming: Internal Timebase. When shipped from the factory, the internal timebase is in CPM for conventional units and the CPS for SI units.

(3) **Detector Sensitivity**

Obtain the sensitivity of the detector from the specification sheet. The example detector has a sensitivity of 2100 CPM/mR/h.

(4) **Deadtime**

The Deadtime value should be listed in the detector specification sheet. Note this value on the worksheet. The Example GM detector has a deadtime of 100 μ Sec or 100×10^{-6} Sec.

b) **Rate Ranges**

(1) **Units**

Determine the rate units that you want the instrument to operate in. The choices are: cnt, REM, rad, R, Sv, Bq, Gy, dis, CPM, CPS, or User programmed. This is the basic unit and does not include the prefix such as m or μ . For example the basic unit of a pancake GM detector is R and not mR. It could also be in rad.

Note the units in the space provided on the worksheet and also the corresponding number from the table on the worksheet.

(2) Prefix

Determine the prefix for the main rate range of the instrument. If you want the instrument to work in $\mu\text{R/h}$ then the basic units would be μ . This assumes that the detector works in that range. Don't try to set the instrument to read in R/h when the basic units should be $\mu\text{R/h}$. For example the Pancake GM detector would want to read in mR/h. $\mu\text{R/h}$ would result in the display being too large a number, and R would result in it being too small a number. Note the prefix and the corresponding number from the table in the worksheet.

(3) Timebase

Select the timebase of /h, /m or /s. If you need another timebase, use the User setting under Units. Note the timebase and the corresponding number from the table in the worksheet.

(4) Calibration Factor and Exponent

If the internal time base is set to CPM then determine the CPM/prefix-units/timebase. For example for a pancake detector that should read in mR/h, determine the CPM/mR/h. This is 2100 CPM/mR/h. If this number is below .1 CPM/prefix-units/timebase or above 10,000 CPM/prefix-units/timebase, then think about changing the prefix up or down to compensate. A detector with 50,000 CPM/mR/h has the prefix set too high. It should be reduced to 50 CPM/ $\mu\text{R/h}$ in which case the prefix would be μ .

If the internal time base is set to CPS then determine the CPS/prefix-base/timebase units. For example for a pancake detector that should read in $\mu\text{Gy/h}$, determine the CPS/ $\mu\text{Gy/h}$ which is 3.5 CPS/ $\mu\text{Gy/h}$. If this number is below 0.01 CPS/prefix-units/timebase or above 1000 CPM/prefix-units/timebase, then think about changing the prefix up or down to compensate.

Take the reciprocal of the number and convert to scientific notation. For example $1/2100 = 0.000476 = 4.76 \times 10^{-4}$. The formula is:

$1/(\text{sensitivity in prefix-units/timebase})$

This is the calibration number. In the example, 4.76 is the Calibration Factor, and -4 is the Exponent. The range of the Exponent is from -10 to +10. If it is beyond this range, change the prefix and recalculate the Calibration Factor and Exponent. Note these values in the worksheet.

(5) Calculating the Maximum Level

The Maximum Range is calculated from the maximum level that can be displayed with the detector which is determined by its deadtime.

1. Calculate the maximum level in CPM or CPS that can be used for the detector. If the deadtime correction is turned on the instrument can be operated at a higher rate than if it is turned off. The instrument will count up to 1 million CPM or 16,666 CPS with deadtime off.

The formula is below. There are 4 possibilities, with and without deadtime, and CPM and CPS timebases. Choose the correct one for your application. The Deadtime is usually turned on for Rate Ranges. Deadtime is in seconds

(15 μsec is 15×10^{-6} Sec). Note the values on the worksheet. For example with a CPM timebase and the deadtime of 100 μSec turned on, the highest level for the GM pancake detector would be: $204/100 \times 10^{-6} = 2,040,000$ CPM

CPM Timebase

Deadtime off: Highest level (CPM) = $46.3/\text{deadtime}$
Deadtime on: Highest level in (CPM) = $204/\text{deadtime}$

CPS Timebase

Deadtime off: Highest level (CPS) = $.772/\text{deadtime}$.
Deadtime on: Highest level (CPS) = $3.4/\text{deadtime}$

2. Calculate the maximum level that can be displayed on the instrument by multiplying the maximum level times the Calibration Factor. Note the value on the worksheet.

Max Level in Units = Max Level in CPM/CPS x Calibration Factor.

For the example this would be $2,040,000 \times 4.76 \times 10^{-4} = 971$ mR/h

This figure can be helpful in determining the maximum range that can be used with the detector.

(6) Determining the Minimum and Maximum Ranges

Now it is necessary to determine the minimum and maximum range. The instrument will calculate and display the appropriate value. At high doserates, when the detector becomes saturated, the display will instantaneously show full scale. If the instrument can use only a small portion of the top scale, it may be better to limit use of that top scale. Likewise at very low count rates, if the bottom scale will be at nearly full scale from background, then that scale is useless. This setting helps to determine the minimum and maximum scales to use. For defaults, the Range Low Limit can be set to 0 and the Range Hi Limit can be set to +5. This can be corrected interactively in actual use in the Detector Setup Menu.

To understand the table below, imagine that the basic units and prefix which have been set from the above steps are in the three places marked 0 in the column marked Range With Prefix Units. The three spaces marked -1 in Range with units would have the next lower prefix, and the 3 spaces marked +1 would have the next higher prefix. The Meridian will automatically select the higher and lower prefix, but you have already set the starting point from the prefix-units/timebase settings made in the above steps.

There are 2 reasons for setting an upper range. The first is that when the instrument detects saturation or too many counts, it will make the Range Hi Limit the range that is shown with the overrange indicators. The other reason is to keep from switching to a high range if only a small portion of it can be used because of saturation or deadtime losses.

The maximum level has been calculated above. Find which range would be the maximum range based on the above calculations. Set the Range Hi Limit to the next higher range. Note the value on the worksheet.

The GM example is shown in the Example column. It has the units-prefix/timebase of mR/h (which was the chosen basic units and prefix) in the three locations marked 0 under Range With Prefix-Units.

With the GM detector example, the maximum range as calculated above is 971 mR/h. 971 would be displayed on as XXX as shown in row 10. Since it is almost at the end of the range, it is best to leave that range whole. The Range Hi Limit would be set to +3 for this example.

The lower range is best to calculate and would correspond to about 600 CPM or 10 CPS Full Scale. If the range goes lower than this, then it may not be usable. The calculation is:

$$\text{Lowest Count Rate} \times \text{Calibration Factor}$$

Where the Lowest Count Rate is 600 CPM if the internal timebase is CPM or 10 CPS if the internal timebase is in CPS. For the example this would be $600 \times 4.76 \times 10^{-4} = 0.286$ mR/h. This would be on range -1 on Detector Setup. The Range Low Limit would be set to -1 in the Detector Setup Menu.

f	DETECTOR SETUP	DISPLAY FROM...	DISPLAY TO...	RANGE WITH PREFIX-UNITS ²	EXAMPLE GM Detector
1	-7	.1	.999μ	-2	
2	-6	1	9.99μ	-2	
3	-5	10	99.9μ	-2	
4	-4	100	999μ	-2	
5	-3	.001	.00999	-1	uR/h
6	-2	.01	.0999	-1	uR/h
7	-1	.1	.999	-1	uR/h
8	0	1	9.99	0	mR/h
9	+1	10	99.9	0	mR/h
10	+2	100	999	0	mR/h
11	+3	1K	9990	+1	R/h
12	+4	10K	99.9K	+1	R/h
13	+5	100K	999K	+1	R/h
14	+6	1M	9.99M	+2	
15	+7	10M	99.9M	+2	
16	+8	100M	999M	+2	

¹ The Row is used for identification purposes only. ²This column represents the prefix. The three places marked 0 would have the basic prefix-units/timebase. The three marked -1 would have the next lower prefix-units/timebase. The three marked +1 would have the next higher prefix-units/timebase. See the example column.

The above table shows the range of the instrument. The 2nd column contains the values that are used in the Detector Setup Menu. These correspond to the values in the 3rd and 4th column that show the range of the instrument. The 5th column is the change in prefix up or down from the selected nominal value.

c) Integrate Range

The setup of the integrate range is similar to the rate range. There are fewer choices in this mode.

(1) Calibration Factor and Exponent using Rate Range.

If the integrate range is in the same prefix-units as the rate range then the same Calibration Factor can be used in calculating the integrate range Calibration Factor. If the rate range is in mR/h and the integrate range in mR then they are considered to have the same units.

Divide the Calibration Factor with Exponent by 60 if the internal timebase is in CPM and by 3600 if the internal timebase is in CPS. This is the new calibration Factor and Exponent for the integrate range. Mark the Units, Prefix, Calibration Factor and Exponent on the worksheet.

(2) Calculating the Calibration Factor and Exponent

If the integrate range is not in the same prefix-units as the rate range, then you need to determine the basic units and prefix that you will want to use.

Calculate the basic prefix-unit per counts.

For example, if the GM pancake detector is to read in mR then do this in 2 steps. First calculate the counts/mR.

$$(2100 \text{ Counts/Min/mR/h}) \times (60 \text{ min/hr}) = 126,000 \text{ counts/mR}$$

Then calculate the mR/counts by taking the reciprocal.

$$1/126,000 = .000,007,93 \text{ or } 7.93 \times 10^{-6}$$

7.93×10^{-6} is the Calibration Factor and Exponent, 7.93 is the Calibration Factor, and -6 is the Exponent. Mark the Units, Prefix, Calibration Factor and Exponent on the worksheet.

(3) Range High and Low Limits

Set the Range High to +8. Set the Range Low to -4. This range will usually be low enough to change with the first few counts. If you want it to be less sensitive, then change to -3 or -2.

d) Overall Detector Settings

The Detector needs its own settings of High Voltage, Discriminator, Gain, and Saturation to function.


(1) High Voltage

The High voltage is usually set by either using the recommended voltage from the manufacturer or by plotting the plateau. Either method will work.

To plot the plateau:

1. Expose the detector in a fixed geometry to a medium intensity radiation source.
2. Slowly raise the high voltage until the detector begins to count. You may need to adjust the discriminator before this step.

3. Raise the high voltage in uniform steps of 50 volts. At each step note the radiation intensity on the CPM/S range. **Do not go above the maximum voltage for the detector.**
4. Plot the High voltage vs. counts on a graph.
5. Adjust the high voltage in the instrument to the value that corresponds to midway on the plateau. If there is no upswing, then adjust it above the knee.



GRAPH OF HIGH VOLTAGE VS COUNTS

(2) Discriminator

The Discriminator is set by lowering the value to the point where the instrument will count from noise, then raising it past the point where it stops counting. Check for double counting at low count rates. Lower the gain or raise the discriminator to correct this problem.

(3) Saturation

The saturation detector if installed, is used to prevent a saturated detector from reading 0 on the display. Set it to 0 to turn it off. To adjust the setting in Detector Setup Mode:

1. Reduce the Saturation to zero.
2. Expose the detector to sufficient radiation so the reading is at the top of the highest scale.
3. Raise the saturation until the reading shows off scale.
4. Lower the saturation by 10%.

e) Other variables and settings

The bargraph type, display type, inverted or normal display, modes for each detector, and range up and down times can be reviewed under the Custom Settings section.

f) Programming the Setup Value

The values on the worksheet may be programmed into the instrument in either of 2 ways. The first and easiest way is to use the Detector Setup Menu. This is an interactive mode that shows the count rate as well as the settings for each of the above items.

The other way is to use the Custom Settings Menu which allows programming into the locations in EEPROM. This is more complicated and involves looking up the locations of each item in the list. We recommend using the Detector Setup Menu. Remember that the Detector that is selected using the Function Menu will be the detector whose parameters you are saving or changing. See the individual sections on how to use these Menus.

If you have problems with the programming and the instrument is functioning in an unpredictable manner, you can revert back to the factory settings under the Setup Menu, however the values for the previous calibration will be lost.

g) Log Bargraph

If you have a Log Bargraph the Range Low Limit sets the low end of the bargraph. Set the Range High Limit as you would if using a normal bargraph. With the log bargraph, the digital display will change ranges at each decade.

I. CUSTOM SETTINGS MENU

The Custom Settings is used to change the individual items in the instrument. It can change any variable. It programs by numbers and does not show the name of the variable. It is necessary to refer to the tables below to determine the location of the variable, and the setting for that variable. A description of the variables follows the tables.

1. Programming

To program the variable, first determine the variable or variables that you want to change. Locate the location of that variable in the following table, then determine the value or setting of the variable from the section Description of Custom Settings. Finally program the new value into that location using the Custom Settings Menu.

NOTE: Some of the variables are only for the instrument, some are for the detector, and some are for the detector and each mode. One is for the instrument and the mode.

1. Disconnect the current detector during this operation if you are changing the high voltage and the new voltage may damage the detector.
2. Turn on the instrument with the **MODE** button pushed down. If this does not result in the words **Calibration *1** in the display then the Front Panel Calibration Adjust has been disabled and it is necessary to use the internal one. The internal Calibration Adjust button is located through a small hole between the two battery holders in the battery compartment. Push on this button while turning the instrument on. The words **Calibration *1** should be on the display.
3. Using the \leftarrow or \rightarrow softbuttons, repeatedly push them until **Custom Settings *5** is visible. Push the **ok** softbutton.
4. The display will now show **Loc Data** on the top line and numbers on the bottom line. These stand for location and data. The location is the place in EEPROM memory that holds the data. The data is the value that is stored in that location. Data and location have values from 0 to 255. The 3 digit number under **Loc** is the current location. The 3 digit number under **Data** is the data for that location.

The right hand softbuttons change the numeric value of the data or location. The \rightarrow softbutton will move the cursor over 1 place and the \leftarrow softbutton will increase the value of the number positioned over the cursor. Using the two buttons, you can change the value of either the location or the data.

The **POWER** button, is a softbutton even though it is not marked. Pushing it will move the cursor from the Location value to the Data value. If the Data has been changed, pushing the **POWER** button will save the data. **This is the only way to save the data.** The display will show the programming message.

Pushing both right hand softbuttons down simultaneously will change the softbuttons from \rightarrow and \leftarrow to \uparrow and \downarrow . In this configuration the softbutton will raise and lower the value of the 3 digit number that is above the cursor. This makes it easier to increase or decrease values, or to scroll through memory.

5. When you are finished, push the **POWER** button to save the last change then push the **MODE** button to return to the Main Setup Menu.
6. It is a good idea to recalibrate or at least check the operation of the instrument to make sure you did not inadvertently change an important variable.

2. Locations of Variables

The tables below show the values in each of the locations. The first table covers locations 0 to 36. The second table covers locations 25 to 27 and 48 to 255.

Locatio	Name	Description
0	Check	Contains Adjust. Power off . EEPROM check value
1	Stats	Buzzer on/off and loud
2	Detector. #	Current detector number set to 0 for detector 1. 1 for detector 2 & 2 for det 3
3	Cur rent Mode	Current mode of instrument. 0=CPM/S.1=Rate.2=User.3=Int.4=Scaler
4	Contrast	Default is 160
5	Time Int3	Time for integrate range 3rd Digiit. Set to 0
6	Time Int2	Time for integrate range 2nd Digiit. Set to 0
7	Time Int1	Time for integrate range 1st Digiit Set to 60
8	Time Sc13	Time for scaler 3rd Digiit. Set to 0
9	Time Sc12	Time for scaler 2nd Digiit. Set to 0
10	Time Sc11	Time for scaler 1st Digiit. Set to 60
11	Not Used	
12	DT on/off	Deadtime on/off for each Mode
13	Detector Max	Detectors that can be used. Set to 1 for 1. 2 for 2 and 3 for 3
14	Power Time	Time before auto turn off. Set to 0 for no turn off.
15	CPM/CPS	Internal Timebase and Sets SI units for Instrument and Detector Setup.
16	* Button	Softkey definition
17	^ Button	Softkey definition
18	Function Mnu 1L	Function Menu softbutton definition for 1st menu left button
19	Function Mnu 1C	Function Menu softbutton definition for 1st menu center button
20	Function Mnu 1R	Function Menu softbutton definition for 1st menu right button
21	Function Mnu 2L	Function Menu softbutton definition for 2nd menu left button
22	Function Mnu 2C	Function Menu softbutton definition for 2nd menu center button
23	Function Mnu 2R	Function Menu softbutton definition for 2nd menu right button
24	Function Mnu 3L	Function Menu softbutton definition for 3rd menu left button
25	Function Mnu 3C	Function Menu softbutton definition for 3rd menu center button
26	Function Mnu 3R	Function Menu softbutton definition for 3rd menu right button
27	User1	User Units and Timebase 1st character
28	User2	User Units and Timebase 2nd character
29	User3	User Units and Timebase 3rd character
30	User4	User Units and Timebase 4th character
31	User5	User Units and Timebase 5th character
32	HV Cal	Calibration number for High Voltage. Preset to 94
33	Power User1	User character at turn on displav. 1st digit.
34	Power User2	User character at turn on displav. 2nd digit.
35	Power User3	User character at turn on displav. 3rd digit.
36	Power User4	User character at turn on displav. 4th digit.

Location Det#1	Location Det#2	Location Det#3	Mode	Name	Description
37	38	39	Mode ¹	Mode Lockout	Determines which modes in
48	112	176	CPM	Cal High	Part of Calibrate Number Digiit

49	113	177	'	Cal Low	Part of Calibrate Number Digt
50	114	178	'	Exponent	Exponent
51	115	179	'	Prefix	Base Prefix
52	116	180	'	Units	Base Units
53	117	181	'	Timebase	Base Timebase
54	118	182	'	Disp Tvpe	Displav Tvpe. Where D point is
55	119	183	'	Barg Tvpe	Bargraph Tvpe
56	120	184	'	Range Hi Limit	Limit for ranging up
57	121	185	'	Range Lo Limit	Limit for ranging down
58	122	186	'	Range Up Time	Time to range up
59	123	187	'	Range Dn time	Time to range down
60	124	188	'	Time Constant	Time Constant
61	125	189	'	Displav Confa	Confiaure the Displav
62	126	190	RATE	Cal High	Part of Calibrate Number Digt
63	127	191	'	Cal Low	Part of Calibrate Number Digt
64	128	192	'	Exponent	Exponent
65	129	193	'	Prefix	Base Prefix
66	130	194	'	Units	Base Units
67	131	195	'	Timebase	Base Timebase
68	132	196	'	Disp Tvpe	Displav Tvpe. Where D point is
69	133	197	'	Barg Tvpe	Bargraph Tvpe
70	134	198	'	Range Up Limit	Limit for ranging up
71	135	199	'	Range Hi Limit	Limit for ranging down
72	136	200	'	Range Lo Limit	Time to range up
73	137	201	'	Range Dn Limit	Time to range down
74	138	202	'	Time Constant	Time Constant
75	139	203	'	Displav Confa	Confiaure the Displav
76	140	204	USER	Cal High	Part of Calibrate Number Digt
77	141	205	'	Cal Low	Part of Calibrate Number Digt
78	142	206	'	Exponent	Exponent
79	143	207	'	Prefix	Base Prefix
80	144	208	'	Units	Base Units
81	145	209	'	Timebase	Base Timebase
82	146	210	'	Disp Tvpe	Displav Tvpe. Where D point is
83	147	211	'	Barg Tvpe	Bargraph Tvpe
84	148	212	'	Range Hi Limit	Limit for ranging up
85	149	213	'	Range Lo Limit	Limit for ranging down
86	150	214	'	Range Up Time	Time to range up
87	151	215	'	Range Dn Limit	Time to range down
88	152	216	'	Time Constant	Time Constant
89	153	217	'	Displav Confa	Confiaure the Displav
90	154	218	INTGRT	Cal High	Part of Calibrate Number Digt
91	155	219	'	Cal Low	Part of Calibrate Number Digt
92	156	220	'	Exponent	Exponent
93	157	221	'	Prefix	Base Prefix
94	158	222	'	Units	Base Units
95	159	223	'	Disp Tvpe	Displav Tvpe. Where D point is
96	160	224	'	Range Hi Limit	Limit for Tvpe ranging up
97	161	225	'	Range Lo Limit	Limit for ranging down
98	162	226	'	Displav Confa	Confiaure the Displav
99	163	227		Not Used	
100	164	228		Not Used	
101	165	229	DET ²	Beeper Divider	Divider for beeper
102	166	230		Not used in this model	
103	167	231	'	Discriminator	Discriminator
104	168	232	'	Not used in this model	
105	169	233	'	Deadtime	Deadtime
106	170	234	'	High Voltage	High Voltage
107	171	235	'	Saturation	Saturation
108	172	236	'	Not used in this model	

NOTES ¹ Setting for the instrument with detector. ²Settings for Detectors not for modes.

3. Description of Custom Settings

The following descriptions are in alphabetical order.

a) * Button

This selects the function of the * button.:

* AND Δ QUICK-KEY BUTTON DEFINITIONS	
Setting	Function of * and Δ button
0	No function, button will do nothing
1	Light on/off
2	Buzzer on/off
3	Time Constant Set
4	Contrast
5	Range Hold
6	Hold/Reset/Run. display in hold
7	Buzzer Divider., Sets buzzer divider
8	Detector Set. Chngs to det 1, 2 or 3
9	Mode Change, changes the Mode

b) Δ Button

This selects the function of the Δ button and has the same choices as the * button.

c) Adjust

See Check

d) Bargraph Type

This is the full scale value of the bargraph. It allows four choices for full scale on the bargraph. This will not change the calibration of the instrument but will alter when the range change occurs. The Digital display will change ranges to keep the bargraph on scale. 10 (Setting 1) is usually used for full scale, however for different applications any of the others are equally applicable.

The 5 decade log display is a quasi log with linear values between the decades. Each decade is represented and each decade is linear. This mode will make the digital display change ranges the same as type 1. Change the bargraph scale inside the instrument (located above the display under the window) if you change this value.

The log bargraph is set with the Range Lo Limit as the beginning of the range.

BARGRAPH TYPE

Setting	Type	Setting	Type
1	1,10,100,1000,1K	3	.25,2.5,25,250,2.5K
2	.5,5,50,500,5085	4	5 decade Log

e) **Beeper Divider**

The beeper divider divides the pulses from the detector before sending them to the beeper. This is useful with detectors that have higher count rates such as scintillators. It is hard to distinguish changes in beep rate when the beeper is on almost all of the time. Setting the divider to a higher number will reduce the number of beeps and make changes more apparent.

BEEPER DIVIDER			
Setting	Divider	Setting	Divider
0	1	2	64
1	8	3	2048

f) **Cal High/Low**

This is the value of the Calibration Factor on all modes except the scaler. It is set for each detector and each mode. It is best set in the Calibrate or Detector Setup Menu. It is in reality a two byte HEX number. The High byte and low byte make up the complete calibrate number. It is set from 100 to 999. This is 100 times greater than the value in the display in the Calibrate Mode because the program takes care of the difference. To set it to 1.00 in the Calibrate Display, set Cal High to 0 and Cal Low to 100. To set it to 5.00 in the Calibrate Display, set Cal High to 1 and Cal Low to 2440.

g) **Check**

This location contains the settings for several variables.

ADJUST on and off for scaler and for other ranges. No turns the adjust off and Yes turns it on. This can also be set by the menu **Front Panel *7** of the Setup Menu.

POWER OFF Turns the power off automatically after the time specified in Power Off Time. Set to no to turn off the automatic power off. If you want it to turn off automatically set it to yes. This can also be set by the menu **Front Panel *7** of the Setup Menus.

FRONT PANEL CALIBRATE Turns on and off the Front Panel Calibrate. Set to No if you want to have to open the instrument to change the calibration. Set it to yes if you want access to the calibration adjustments through the front panel. This can also be set by the menu **Front Panel *7** of the Setup Menus.

CHECK TABLE				
Setting	Adjust Scaler	Adjust All modes	Auto Power Turnoff	Front Panel Calibrate
10	No	No	No	No
26	No	No	No	Yes
42	No	No	Yes	No
58	No	No	Yes	Yes
74	No	Yes	No	No
90	No	Yes	No	Yes
106	No	Yes	Yes	No
122	No	Yes	Yes	Yes
138	Yes	No	No	No

CHECK TABLE				
Setting	Adjust Scaler	Adjust All modes	Auto Power Turnoff	Front Panel Calibrate
154	Yes	No	No	Yes
170	Yes	No	Yes	No
186	Yes	No	Yes	Yes
202	Yes	Yes	No	No
218	Yes	Yes	No	Yes
234	Yes	Yes	Yes	No
250	Yes	Yes	Yes	Yes

h) **Contrast**

Sets the contrast of the instrument. This is normally set with the Contrast adjustment **LCD** softbutton. It is preset to 160 in the Factory Setting. If this is incorrectly set it may be impossible to read the LCD. If that is the case use the Emergency Contrast Adjustment.

i) **CPM/CPS Internal Timebase**

This selects the internal timebase of the instrument. There are 2 choices, CPM (Counts per minute) or CPS (Counts per second). If this is set to CPM and then programmed with the Instrument Setup, Detector Setup or Factory Setup menus, the instrument will be in conventional units and the rate range will probably read in mR/h. If it is set to CPS and then programmed with one of the 3 Setup menus, the instrument will be in SI units. Set this to 0 for Conventional Units, and 1 for SI units or use one of the choices in the Setup Menus.

There is another reason for using CPM or CPS. One of the choices with the **MOD** softbutton in the Function Menu during normal operation is CPM. If you want this to be CPS then you must choose the CPS internal timebase. If you want it to be CPM then you must choose the CPM internal timebase. If you change this setting, then you must recalibrate the instrument. For more information see the section on Programming: Internal Timebase.

j) **Current Mode**

This is the current mode. Set it to a mode that is currently in use. Also see Mode Lockout.

CURRENT MODE TABLE					
MODE	CPM/S	RATE	USER	INTEGRATE	SCALER
SETTING	0	1	2	3	4

k) **deadtime**

This should be the Deadtime for the detector and if the Deadtime is turned on, will correct for dead time losses at high count rates. Set it in microseconds from 0 to 255.

l) **Detector #**

This is the current detector that is in use. It determines which detector is in use not how many detectors. Set to 0 if you have only 1 detector. Set it to 0 if you have several detectors and use the **DET** softbutton in normal operation to change the value. Its value is changed every time the detector number is changed.

m) **Detector Max**

This limits the number of detectors that can be selected by the DET softbutton in a Function Menu. Set it to 1 for 1 detector, 2 for 2 detectors, and 3 for 3 detectors.

n) Discriminator

This setting may also be thought of as a threshold. It should be set high enough that there are no counts from noise. It may be set from 0 to 255 but is linear only from 0 to 100. It is best set interactively in the Detector Setup Menu.

o) Display Configuration

Changes the look and feel of the display. The Bargraph can be turned on and off as can the Numeric Display in the CPM/S, Rate and User modes. The Display can be set to normal with the bargraph on the bottom or it can be inverted with the bargraph on the top. The Bargraph scale can be set to flash.

DISPLAY CONFIGURATION					
Setting		Bargraph	Rate Numbers	Normal/Invert	Flash Barg S.
0	128*	off	off	normal	No flash
1	129*	on	off	normal	No flash
2	130*	off	on	normal	No flash
3	131*	on	on	normal	No flash
4	132*	off	off	inverted	No flash
5	133*	on	off	inverted	No flash
6	134*	off	on	inverted	No flash
7	135*	on	on	inverted	No flash
8	136*	off	off	normal	Flash
9	137*	on	off	normal	Flash
10	138*	off	on	normal	Flash
11	139*	on	on	normal	Flash
12	140*	off	off	inverted	Flash
13	141*	on	off	inverted	Flash
14	142*	off	on	inverted	Flash
15	143*	on	on	inverted	Flash

p) Display Type

There are 4 display types. They change the way the data changes the prefix when it changes ranges. The 4 types and their settings are:

1. This is engineering format. The units change every 3 decades.
2. This extends the engineering format up 1 so that a prefix change will not occur when the value moves above 999. For example instead of going from 999 mR/h to 1.00 R/h this will go from 999 mR/h to 1000 mR/h with a constant zero in the right hand digit. On the next higher decade change the prefix will change.
3. This extends the engineering format down 1 decade so that a prefix change will not occur when the value goes below 100. For example instead of going from 1.00 mR/h to 999 uR/h the display would go from 1.00 mR/h to .999 mR/h. On the next lower decade the display would change the prefix.
4. This is a combination of 2 and 3 where the span of one prefix will be extended up and down 1 decade. This is usually the recommended setting.

DISPLAY TYPE			
Setting	Type	Setting	Type
1	Engineering format	3	Down 1 decade

2	up 1 decade	4	Up & Dn 1 Decade
---	-------------	---	------------------

q) Dt On/Off

Use the same table as in Mode Lockout. This controls if the deadtime is turned on or off for each Mode. If it is set to ON then the deadtime is turned on. The common setting is 10 which turns the deadtime correction on only for the Rate and Integrate modes.

r) Exponent

This is the value of the Exponent in the instrument. It is a positive and negative number that rolls negative at 255. Thus 0 is zero, 5 is +5 and 252 is -4. It is best set in the Calibrate or Detector Setup Menu.

EXPONENT TABLE			
Setting	Exponent	Setting	Exponent
1	1	0	0
2	2	255	-1
3	3	254	-2
4	4	253	-3
5	5	252	-4
6	6	251	-5
7	7	250	-6
8	8	249	-7
9	9	248	-8
10	10	247	-9

s) Front Panel Calibrate

See Check

t) Function Menus

There are 12 different possibilities for the Function Menus. These are the softbuttons. 1L refers to the 1st Function Menu after you push the MODE button and the L refers to the left hand softbutton (really the MODE button). C is the center softbutton (really the * button) and R is the right softbutton (really the . Δ button). There are therefore 3 possible Function Menus each with 3 possibilities.

If a complete function menu is programmed with 0 in all three locations, then the previous Function Menu will be the last one displayed.

FUNCTION MENU SOFTBUTTON DEFINITIONS	
Setting	Function
0	None. Display will be blank and Softbutton will do nothing
1	Light on/off/timed
2	Buzzer on/off/soft
3	Time Constant slow/medium/fast
4	Contrast adjustment
5	Range Hold which keeps the same range
6	Hold Freezes the numeric display
7	Beeper Divider. Set to 1,8,64 or 2048 counts/beep
8	Detector number. Changes the number of the current detector.
9	Deadtime in/out Choose for each mode
10	Mode selects from CPM/S, Rate, User, Intgrt, Scaler
11	Calibrate Changes to calibrate mode
12	Window Turns window on or off

u) High Voltage

This is the actual high voltage setting. Set it from 0 to 255. The value of the high voltage is 9.8 volts per unit. This is an approximate setting. Check the actual setting for each detector in the Calibration or Setup Menu.

HIGH VOLTAGE SETTINGS 9.8 Volts/unit of setting This table has some common settings for high voltage.	
Setting	Volts
45	450
71	700
92	900
143	1400
173	1700

v) High Voltage Cal

This is a factor that calibrates the high voltage displays in the Meridian. It does not change the value of the actual high voltage. This is best set in the High voltage Calibrate Setup Menu. Its nominal value is 90. See the Maintenance section for details on setting this variable.

w) Mode Lockout

This determines which modes can be displayed. Set it to off if it is a mode you do not want. Set it to on if it is a mode you want to be able to choose with the MOD softbutton. A common setting is 27 which turns on all the Modes except the User Mode. The Current Mode should be set to one of the modes that is on.

MODE LOCKOUT AND DT ON/OFF TABLE					
Setting	CPM/S	RATE	USER	INTEGRATE	SCALER
0	off	off	off	off	off
1	on	off	off	off	off
2	off	on	off	off	off
3	on	on	off	off	off

4	off	off	on	off	off
5	on	off	on	off	off
6	off	on	on	off	off
7	on	on	on	off	off
8	off	off	off	on	off
9	on	off	off	on	off
10	off	on	off	on	off
11	on	on	off	on	off
12	off	off	on	on	off
13	on	off	on	on	off
14	off	on	on	on	off
15	on	on	on	on	off
16	off	off	off	off	on
17	on	off	off	off	on
18	off	on	off	off	on
19	on	on	off	off	on
20	off	off	on	off	on
21	on	off	on	off	on
22	off	on	on	off	on
23	on	on	on	off	on
24	off	off	off	on	on
25	on	off	off	on	on
26	off	on	off	on	on
27	on	on	off	on	on
28	off	off	on	on	on
29	on	off	on	on	on
30	off	on	on	on	on
31	on	on	on	on	on

x) Power Off

See Check

y) Power Time

This is the timer for the automatic turn off. It sets in increments of 25.5 seconds and can be set from 0 to 255. It is preset to 255 which is 108 minutes. This means that the instrument will automatically turn off in 108 minutes after the last button has been pushed.

z) Power User 1 Thru 3.

This allows any 3 characters to be displayed on the right hand side of the LCD at turn-on. See the ASCII table under User below for the setting of the character. Power User 1 is the left hand character.

aa) Prefix

The prefix is the starting point for all the modes except the Scaler.

PREFIX TABLE			
Setting	Prefix	Setting	Prefix
0	a atto	7	K kilo

1	f femto	8	M mega
2	p pico	9	G giga
3	n nano	10	T tera
4	u micro	11	P penta
5	m milli	12	E exa
6	none		

bb) Range Hi/Lo Limits

This sets the limits of the display, both upper and lower limits. It has the value from 119 to 136 with 128 in the center. Set this to keep the detector from being too sensitive and to keep it from going into a high scale that may not be usable because of saturation or excessive deadtime losses..

RANGE HI/LO TABLE Center is the point of calculation for the calibration. Higher means the ranges with more counts. Lower means the ranges with fewer counts.			
Setting	Range (decade)	Setting	Range (decade)
128	X.XX Center	127	XXX
129	XX.X	126	XX.X
130	XXX	125	X.XX
131	X.XX	124	XXX
132	XX.X	123	XX.X
133	XXX	122	X.XX
134	X.XX	121	XXX
135	XX.X	120	XX.X
136	XXX Higher	119	X.XX Lower

cc) Range Up/Dn Time

This is the number of seconds that it takes the rate ranges to change ranges. The value set is the number of seconds. It is normally set to 0. Setting the Up Time to 3, for example will delay moving up a range for 3 seconds.

dd) Saturation

This is useful to check if the detector is in saturation or drawing too much current. It should be set interactively with the detector under the Setup Menu. Its range is from 0 to 255. If it is set too high, it could cause the instrument to read off scale on all ranges with no detector.

ee) Stats

This controls the beeper status. It is normally set and adjusted by the BUZ softbutton depending on the Mode. The loud/soft adjustment also effects the Quick-key when it is set to beeper on/off. Set the loud/soft correctly if you want the Quick-key to be soft or loud and you have no BUZ softbutton. Set this if you have no BUZ softbutton.

STATS TABLE				
Setting	Beeper Volume Int/Scaler	Beeper int/scaler	Beeper volume all rate ranges	Beeper all rate ranges
0	soft	off	soft	off
1	soft	off	soft	on
2	soft	off	loud	off

3	soft	off	loud	on
4	soft	on	soft	off
5	soft	on	soft	on
6	soft	on	loud	off
7	soft	on	loud	on
8	loud	off	soft	off
9	loud	off	soft	on
10	loud	off	loud	off
11	loud	off	loud	on
12	loud	on	soft	off
13	loud	on	soft	on
14	loud	on	loud	off
15	loud	on	loud	on

ff) Time Constant

This sets the speed of the bargraph and the rate of change of the display. It is also set by the TC softbutton.

TIME CONSTANT			
Setting	Time Constant	Setting	Time Constant
0	Fast	2	Slow
1	Medium		

gg) Time Int

This is the setting of the time for the time in the integrate range. It is set by the integrate range. Time Int1 is the MSB of a 3 byte HEX number. Each portion of the number is presented in decimal. The 3 byte number is the number of seconds that are in the display. It is preset to 60 which makes the display turn on with 60 seconds or 1 minute. There would normally be no reason to change this setting.

hh) Time Sc1

This is the setting of the time for the scaler. It is set by the time in the scaler. Time Sc1 is the MSB of a 3 byte HEX number. Each portion of the number is presented in decimal. The 3 byte number is the number of seconds that are in the display. It is preset to 60 which makes the display turn on with 60 seconds or 1 minute. There would normally be no reason to change this setting.

ii) Timebase

This has 4 possible settings and sets the characters in the display. Changing this does not change the calibration.

TIMEBASE TABLE			
Setting	Timebase	Setting	Timebase

0	none	2	/m
1	/h	3	/s

jj) Units

The units select which units are used in all modes except the Scaler..

UNITS TABLE			
Setting	Units	Setting	Units
0	cnt	6	Gy
1	REM	7	dis
2	rad	8	CPM
3	R	9	CPS
4	Sv	10	user 1 thru 5
5	Bq		

kk) User 1 Thru 5

This allows any characters to be used for the units and timebase. If user is chosen under Units then these 5 characters will occupy the space for units and timebase. They are normal ASCII characters. Each one needs to be programmed with its own character. User 1 is the left hand character.

ASCII CHARACTER TABLE							
# ¹	CH ²	# ¹	CH ²	# ¹	CH ²	# ¹	CH ²
32	(space)	48	0	64	@	80	P
33	!	49	1	65	A	81	Q
34	"	50	2	66	B	82	R
35	#	51	3	67	C		S
36	\$	52	4	68	D	84	T
37	%	53	5	69	E	85	U
38	&	54	6	70	F	86	V
39	'	55	7	71	G	87	W
40	(56	8	72	H	88	X
41)	57	9	73	I	89	Y
42	*	58	:	74	J	90	Z
43	+	59	;	75	K	91	[
44	,	60	<	76	L	92	Y
45	-	61	=	77	M	93]
46	.	62	>	78	N	94	^
47	/	63	?	79	O	95	_

¹Setting, ²Character

There are settings from 0 to 255, however they are not normal ASCII characters. If you need a strange character, please contact the factory.

J. QUESTIONS & PROBLEMS

There are many questions and problems that can occur with the Meridian. We recommend reading the pertaining sections to try to understand the instrument. Most problems will occur because of incorrect programming.

Q: I programmed the instrument using the custom settings and now I get gibberish on the display when I cycle through the second screen of the Function Menu.

A: The gibberish is a result of an improper programming choice in the Custom Settings. If the choice is not among those that are in the tables, then the instrument will choose a non existing choice and print gibberish on the display. Look at the numbers in locations 18 through 26 using the Custom Settings Menu. The selections should be in the range from 0 to 12.

Q: I want to use 2 detectors but I can't figure out how to change to the second detector.

A: If you can't change the detectors this means that you don't have the DET function in the Function Menu. You will need to add it by changing one of the selections in location 18 through 26 in the Custom Settings Menu. These locations correspond to the left, center and right buttons of the first, second and third Function Menus. To see what the current choices are, look them up in the chart of Function Menu Definitions chart, and then change one of the locations. You will change it to an 8 which is the detector selector. Incidentally you probably are not using all three Function Menus and your choice will be either to change one of the existing softbuttons to this function or to add it to a new Function Menu by adding a Function Menu to location 24, 25 or 26.

Q: Is the Meridian available in different languages?

A: It currently is available only in English. However if you write the words and abbreviations that you want, we will change the program. There is a fee for this service.

Q: I need 2 different scales for the bargraph. How do I do it.

A: The bargraph can be on the top or the bottom line. Use one range with the top line, and one with the bottom line. You will find it under Display Configuration. Make sure the scales are in place on top of the LCD.

Q: When I use the highest range and the reading is about mid scale, it then jumps off scale. I can't get it to read at the top end of the scale. Why not?

A: There are 2 reasons for jumping off scale. If the instrument thinks that the detector is in saturation or if the instrument thinks that there are too many counts for the detector it will make it go off scale. Check the saturation setting, it may be too high. The instrument uses the deadtime setting to calculate how high it should go before showing off scale. It does this even though the deadtime is turned off. To remove the limits, set the saturation and deadtime to 0. This will turn them both off but it may change the calibration.

I. APPENDIX A WORKSHEET

DETECTOR SETUP

Detector Name	Detector Type
Detector Serial Number	1a Det will be DET1 <input type="checkbox"/> DET2 <input type="checkbox"/> DET3 <input type="checkbox"/>
1b Internal Timebase <input type="checkbox"/> CPM <input type="checkbox"/> CPS	1c Sensitivity (i.e. CPM/mR/h)

1d deadtime

RATE RANGE

2a Units: Setting: 2b Prefix: Setting:

2c Timebase: Setting:

2d1 Calculate CPM/S per prefix-units/timebase

2d2 Reciprocal of step 2d1 Calibration Factor:	Exponent
---	----------

2e1 Max Level

2e2 Max Level in display

2f Max Range (Range Hi Limit)

Min Range (Range Lo Limit)

INTEGRATE RANGE

3a Prefix: Setting: Units: Setting:

Same as Rate? YES NO If no use step 3b directly

If yes, Cal Factor x 60 (CPM) or 3600 (CPS) = (put value below)

3b Calibration Factor Exponent

OVERALL DETECTOR SETTINGS **Either Calculate or use Detector Setup Menu interactively. Either way record value.**

4a High Voltage

4b Discriminator

4c Gain

4d Saturation (if installed)

Program the above values using the Detector Setup Menu.

Use Tables below for determining the settings. You will need both the setting and the value.

UNITS TABLE

Setting	Units	Setting	Units
0	cnt	6	Gy
1	REM	7	dis
2	rad	8	CPM
3	R	9	CPS
4	Sv	10	user 1 thru 5
5	Bq		

PREFIX TABLE

Setting	Prefix	Setting	Prefix
0	a atto	7	K kilo
1	f femto	8	M mega
2	p pico	9	G giga
3	n nano	10	T tera
4	u micro	11	P penta
5	m milli	12	E exa
6	none		


TIMEBASE TABLE


Setting	Timebase	Setting	Timebase
0	none	2	/m
1	/h	3	/s


Fill out this table like the Example to determine the min. and max. range.
Remember the Maximum range is the range above the highest displayed.






f	DETECTO R SETUP	DISPLAY FROM.	DISPLAY TO..	RANGE WITH PREFIX-UNITS ²	EXAMPLE GM Detector
1	-7	.1	.999μ	-2	
2	-6	1	9.99μ	-2	
3	-5	10	99.9μ	-2	
4	-4	100	999μ	-2	
5	-3	.001	.00999	-1	uR/h
6	-2	.01	.0999	-1	uR/h
7	-1	.1	.999	-1	uR/h
8	0	1	9.99	0	mR/h
9	+1	10	99.9	0	mR/h
10	+2	100	999	0	mR/h
11	+3	1K	9990	+1	R/h
12	+4	10K	99.9K	+1	R/h
13	+5	100K	999K	+1	R/h
14	+6	1M	9.99M	+2	
15	+7	10M	99.9M	+2	
16	+8	100M	999M	+2	

II. APPENDIX B SCHEMATICS









INDEX

A

Adjust, 10, 11, 21, 22
 Menu, 11
 On/Off, 11
 Using, 11
Appendix
 A Worksheet, 28
Automatic Turn Off Menu, 11

B

Backlight, 13
Bargraph, 4
 Log, 19, 22
 Printed Scale, 12
 type, 19
 Type, 21
Battery, 3
 Change, 5
 Low, 4, 5
Beeper, 13, 25
 Divider, 14
 Divider, 22
Button, 12
 Δ , 21
 *, 21
BUZ, 13

C

CAL, 10, 14
Calibrate, 22
 Cal Button, 10
 Factor, 7
 Menu, 10
 Mode, 14
 Verify CPM, 7
MODEL 5085 MERIDIAN

Verify Scaler, 7
Calibration, 7, 10
 Button, 10
 Factor, 7, 8, 18, 22
 Calculating, 17
 Integrate Mode, 8
 Menu, 10, 15
 Rate Mode, 7
Check, 22
Contrast, 13, 22
 Emergency, 3
CPM, 13, 16
CPM Timebase, 11
CPS, 16
Current Mode, 22
Custom Settings, 21
 Menu, 10, 20

D

Deadtime, 5, 13, 16, 22, 23, 27
 Factor, 7
DET, 13
DET SETUP, 15
Detector, 13
 1,2 or 3, 13
 Connection, 5
 Max, 23
 Number, 22
 Sensitivity, 16
 Settings, 18
 Setup Menu, 10, 15, 16
 Variables, 14
Detector Plateau, 8
Discriminator, 19, 23
Display, 12
 Configuration, 23
 type, 19
 Type, 23
DIV, 14
DK, 13

Health Physics Instruments

DTM, 13

E

EEPROM, 9
Engineering Format, 23
Exponent, 8, 18, 23
 Calculating, 17
EXPONENT, 7

F

Factory Setting, 9, 10, 15, 20
Factory Setting Menu, 11
Failure
 #1, 3, 9
 Reprogramming EEPROM, 9
Front Panel
 Calibrate, 22
 Menu, 10, 11
FST, 13
Function Menu, 12, 13, 24

H

^H, 13
High Voltage, 24
 Cal, 24
 Calibration, 9, 11
 Setting, 18
 Setting Menu, 11
HLD, 13
Hold, 13
HOLD, 13
Hours remaining, 3

I

IN, 13
Instrument Variables, 14
INT, 4, 13
Integrate
 Calibration, 8, 18
 range, 4
 Range Calculation, 18
 Range Setup, 18
Internal Timebase, 12, 14, 16, 22
 Menu, 11
INTG, 2
Introduction, 2

L

Languages, 27
LBAT, 4
LCD, 13
LT, 13

M

Maintenance, 9
 Menu, 11
 Mode, 9
MED, 13
Memory Locations, 20
Menu
 Adjust, 11
 Calibration, 15
 Custom Settings, 20
 Function, 13
 Selecting, 10
 Setup, 10
 Viewing, 10
MHV, 5

MOD, 13
Mode, 12, 13
 Calibrate, 14
 Description, 4
 Lockout, 24
 Rate, 4
 User, 16
MODE, 2, 4

N

NEXT, 2
Numeric display, 4
NXT, 13

O

OFF, 13, 14
ON, 13, 14
Operational, 5
OUT, 13
Overrange, 4

P

Plateau, 8, 18
Power
 Off, 22
 Time, 24
 User, 24
POWER, 2, 3
Prefix, 16, 17, 25

Table, 18, 28
Problems, 27
Programming, 14
 Custom Settings, 20
 Setup Values, 19

Q

Questions, 27
Quick Start, 2
Quick-key, 3, 10, 12
 Programming, 21
 Table, 21

R

Range
 Calculating Maximum, 17
 Calculating Minimum, 17
 Down Time, 25
 High Limit, 17, 25
 Integrate, 4
 Low Limit, 17, 25
 Up Time, 25
Range High Limit
 Calculating, 17
 Integrate Range, 18
Range Hold, 13
Range Low Limit, 18
 Integrate Range, 18
Rate Ranges, 16
Reset, Emergency, 3
RH^H, 13

RS232, 6
RST, 4
RTE, 13

S

Saturation, 19, 25, 27
sav, 11
Scientific notation, 7
SCL, 13
serial, 6
SET, 13
Set Time Mode., 4
SETTIME, 4
Settings, 16
Setup
 Menu, 10
 Menus Accessing, 10
 Programming, 19
Setup Menus, 10
SFT, 13
SLO, 13
Softbutton, 24
Specifications, 1
Stats, 25
STP, 4

T

TC, 13
Terminal, 6
Time
 Integrate Range, 25

Scaler, 25
 Setting, 4
TIME, 2
Time Constant, 13, 25
Timebase, 16, 17, 26
TME, 4, 13

U

Units, 16, 26
Update speed, 4
User
 Characters, 26
 Mode, 16
 Setting, 24
USR, 13, 16

V

Variables, 12, 14, 20
 Detector, 14
 Table, 20
version number, 3

W

Worksheet
 Detector Setup, 28