



Status LED Blinkzustände für UPSI-Geräte mit älterer Firmware-Version

Gültig für

UPSI-1208,
UPSI-2406,
UPSI-1208D,
UPSI-2406D,
UPSI-1208DPx,
UPSI-2406DPx,
UPSI-1208IP-xxxx und
UPSI-2406IP-xxxx

mit einer **Firmware-Version niedriger als 2.1.19.**

Gültig für

UPSI-2412 und
UPSI-2412D

mit einer **Firmware-Version niedriger als 2.2.6.**

1 x blinken, Pause 1,5s	Status: Batteriestart
2 x blinken, Pause 1,5s	Status: Es wird Kapazität zum Starten benötigt, Zustand Laden
3 x blinken, Pause 1,5s	Status Herunterfahren: Warten bis System heruntergefahren ist
4 x blinken, Pause 1,5s	Status Neustart: Ausgang ist abgeschaltet und Zeit läuft bis Neustart (Rebootphase)
5 x blinken, Pause 1,5s	Status: Keine Batterie erkannt
6 x blinken, Pause 1,5s	Batteriespannung zu hoch, Batterie deaktiviert
7 x blinken, Pause 1,5s	Ladestrom zu hoch, Batterie deaktiviert
1 Hz Blinken > Netzausfall	Status: Batteriebetrieb
Dauer An	Status: System OK
Schnelles Blinken	Kritischer Fehler Status: Ausgangsspannung zu gering > USV wird abgeschaltet Status: Überstrom erkannt > USV-Ausgang wird deaktiviert Status: Kurzschluss am Ausgang > USV-Ausgang wird deaktiviert Status: Interner Fehler > USV wird deaktiviert



Status LED flashing states for UPSI devices with an older firmware version

Valid for

UPSI-1208,
UPSI-2406,
UPSI-1208D,
UPSI-2406D,
UPSI-1208DPx,
UPSI-2406DPx,
UPSI-1208IP-xxxx and
UPSI-2406IP-xxxx

with a **firmware version lower than 2.1.19.**

Valid for

UPSI-2412 and
UPSI-2412D

with a **firmware version lower than 2.2.6.**

1 x flash, pause 1.5 s	Status: Battery start
2 x flash, pause 1.5 s	Status: Capacity for start is required, state charging
3 x flash, pause 1.5 s	Status shutdown: Waiting for shutdown completion
4 x flash, pause 1.5 s	Status reboot: Output is switched off and time runs until restart (Reboot)
5 x flash, pause 1.5 s	Status: No battery recognized
6 x flash, pause 1.5 s	Battery voltage too high, battery disabled
7 x flash, pause 1.5 s	Charge current too high, battery disabled
1 Hz flash > power fail	Status: Backup mode
Always on	Status: System OK
Quick flashing	Critical Error Status: output voltage too low > UPS will be shut down Status: Overcurrent detected > UPS will be shut down Status: Short circuit at the output > UPS output is deactivated Status: Internal failure > UPS output is deactivated