

DJI Lightbridge Remote Controller



DJI Mavic Air Remote Controller



DJI Cendence S Remote Controller



DJI T16 Remote Controller



DJI T16 Remote Controller



Keyboard

Pause	P	Gimbal Upward	R
Shutter	H	Gimbal Downward	F
Record/ Stop	L	Switch Views	C
Flight Route	Space	Flight Mode	V
Return to home/ Cancel	O	Switch btw Drone/ Pilot	J
Jump	Space	Minimap	M
Custom Menu	Enter	Introduction Panel	I

Control Stick Settings

