


The front tender base



The front tender base



Your parts



Front tender base

Frame A

Frame B

Member A

Member B

Member C

Member D

Screws (2 x 2mm) x 3

Screws (2 x 3mm) x 5



Screws (2 x 4mm) x 12

Required tools

Phillips screwdriver

1 Fitting the frames

Tighten a 2 x 4mm screw into the single end hole of the frame.




Align the circled screw holes of frame B with the corresponding holes of the tender base. You may find it easier to do this by moving the frame in the way suggested by the arrow.




Place frame A over the same holes on the opposite side of the tender base, and tighten a 2 x 4mm screw into the single hole at the end (circled).


2 Fitting the members




3 Fitting the front tender base




4 Securing the front tender base



Assembled parts




The rear tender base



The rear tender base



Your parts




Member A
Member B
Member C
Member D
Rear tender base
Frame A
Frame B
Screws (2 x 4mm) x 14

Required tools
Phillips screwdriver

1 Fitting the frames



Fit the end of the frame into the groove of the underframe, then align the holes.



Locate the three circled holes of the tender base with corresponding positions to those on frame B.




Follow the same process to fit frame A onto the opposite side of the tender base.




Tighten a 2 x 4mm screw into the single hole at the end of the frame.

2 Fitting the members 1




Place member C over the two holes of frame B and the single hole of the side beam.

Tighten a 2 x 4mm screw into the three holes.



Repeat for the other side of the tender base, using member D.


4 Fitting the members 2




Align the end holes of member B with those of the underframe and side beam.



Tighten a 2 x 4mm screw into both holes of member B.




Tighten a 2 x 4mm screw into each hole.



Place member A on the opposite side of the base, aligning the circled holes.

3 Fitting the rear tender base




Place the rear tender base in the gap between the underframes and the base.




Push the rear in until the holes are aligned.


Assembled parts



The tender



Your parts




Rear tender wall
Tender joint A
Tender joint B
Left front tender edging
Right front tender edging
Screws (2 x 2mm) x 29
Right tender wall
Left tender wall


Required tools

Phillips screwdriver
Contact adhesive


1 Fitting the tender joints




Align the holes of tender joint B with the back of the left tender wall.



Tighten a 2 x 2mm screw into the two circled holes.




Tighten a 2 x 2mm screw into each circled hole.




Align the two holes of tender joint A with the back of the right tender wall.


2 Assembling the tender 1




3 Assembling the tender 2




4 Fitting the edging pieces



Assembled parts



The tender edging



Your parts




Tender edging pieces A x 2
Tender edging piece B
Tender edging piece C
Tender edging piece D

Required tools

Contact adhesive


1 Fitting the edging pieces 1



Place the tender assembly and edging pieces C and D as shown.




Place piece D against the tender wall, aligning the top edges (highlighted).




2 Fitting the edging pieces 2



Apply contact adhesive to the side of tender edging piece A.



Place piece A on the side of the tender between the front and back edging pieces.




Also make sure that it is flush with the pieces either side.




Adjust the placement of the edging so it is aligned with the top of the wall.


3 Fitting the edging pieces 3



Apply contact adhesive to the second A piece.




Place the second A piece up against the top of the right wall.




Adjust the placement of the piece so it is aligned with the top of the wall and the pieces on either side.


4 Fitting the edging pieces 4



Apply contact adhesive to one side of edging piece B.



Place piece B at the back of the tender, up against the top of the wall.



Adjust the position of the edging piece before the glue dries, so it is aligned with the top of the wall.

Assembled parts

